



**RS Stock No.
464-482**

Insulated Crimp Tool For Crimping Bootlace Ferrules.

**For RS and other makes of
bootlace ferrules with the
same barrel size.**

1. Remove 7mm of insulation from the end of the wire to be terminated.
2. Select the correct ferrule to suit cable size. It is important to use the correct size ferrule.
3. Insert the bare wire into the barrel of the ferrule.
4. Crimp the metal barrel of ferrule using tool. Do not crimp polypropylene sleeve.