

3526 Series Impact Punchdown Tools

Operating instructions:

1. If it is not already installed, insert the required blade in the top of the tool by pulling down the spring-loaded locking mechanism, inserting blade & releasing mechanism.
2. Place the un-stripped telephone wire in the termination panel contact at the IDC center location.
3. Locate the tool blade over the wire & contact. Press down the tool in a firm, steady motion until the wire seats in the contact.
4. Remove the tool from the contact.
5. If using the cut/punch side of the blade, the excess cable will be cut off.

