

**Selector Switches (Continued)**

**60° Throw Non-illuminated Lever and Knob Operated Selector Switches**

**Note:** Will accept a maximum of 2 contact blocks (4 circuits) with supplied 3-way mounting adapter. Optional 5-way adapter will accept a maximum of 5 contact blocks (10 circuits). See Page 47-77.

**Table 47-65. 60° Throw Non-illuminated Lever and Knob Operated Selector Switches — UL (NEMA) Type 3, 3R, 4, 4X, 12, 13**

|          |            |           | Operating Mode<br>M = Maintained<br>S = Momentary |                  |                     | Cam<br>Code    | E22 Series —<br>Plastic Operators |                     |                  |                     | EM22 Series —<br>Metal Operators |  |
|----------|------------|-----------|---|------------------|---------------------|----------------|-----------------------------------|---------------------|------------------|---------------------|----------------------------------|--|
| Left<br> | Center<br> | Right<br> | Black Bezel                                       |                  | Chrome Bezel        |                | Chrome Bezel                      |                     |                  |                     |                                  |  |
|          |            |           | Catalog<br>Number ①                               | Price<br>U.S. \$ | Catalog<br>Number ① |                | Price<br>U.S. \$                  | Catalog<br>Number ① | Price<br>U.S. \$ | Catalog<br>Number ① | Price<br>U.S. \$                 |  |
|          |            |           | <b>2-Position — 60° Throw — Black Lever</b>       |                  |                     |                |                                   |                     |                  |                     |                                  |  |
| —        | M          | M         | 2   | <u>E22VBF61</u>  |                     | <u>E22VF61</u> |                                   | <u>EM22VF61</u>     |                  |                     |                                  |  |
| M        | —          | M         | 2   | <u>E22VB561</u>  |                     | <u>E22V561</u> |                                   | <u>EM22V561</u>     |                  |                     |                                  |  |
| —        | M          | S         | 2   | <u>E22VBE61</u>  |                     | <u>E22VE61</u> |                                   | <u>EM22VE61</u>     |                  |                     |                                  |  |
| M        | —          | S         | 2   | <u>E22VB661</u>  |                     | <u>E22V661</u> |                                   | <u>EM22V661</u>     |                  |                     |                                  |  |
|          |            |           | <b>3-Position — 60° Throw — Black Lever</b>       |                  |                     |                |                                   |                     |                  |                     |                                  |  |
| M        | M          | M         | 1   | <u>E22VBG61</u>  |                     | <u>E22VG61</u> |                                   | <u>EM22VG61</u>     |                  |                     |                                  |  |
| M        | M          | M         | 2   | <u>E22VBH61</u>  |                     | <u>E22VH61</u> |                                   | <u>EM22VH61</u>     |                  |                     |                                  |  |
| S        | M          | M         | 1   | <u>E22VBJ61</u>  |                     | <u>E22VJ61</u> |                                   | <u>EM22VJ61</u>     |                  |                     |                                  |  |
| S        | M          | M         | 2   | <u>E22VBK61</u>  |                     | <u>E22VK61</u> |                                   | <u>EM22VK61</u>     |                  |                     |                                  |  |
| S        | M          | S         | 1   | <u>E22VBL61</u>  |                     | <u>E22VL61</u> |                                   | <u>EM22VL61</u>     |                  |                     |                                  |  |
| S        | M          | S         | 2   | <u>E22VBM61</u>  |                     | <u>E22VM61</u> |                                   | <u>EM22VM61</u>     |                  |                     |                                  |  |
| M        | M          | S         | 1   | <u>E22VBN61</u>  |                     | <u>E22VN61</u> |                                   | <u>EM22VN61</u>     |                  |                     |                                  |  |
| M        | M          | S         | 2   | <u>E22VBP61</u>  |                     | <u>E22VP61</u> |                                   | <u>EM22VP61</u>     |                  |                     |                                  |  |
|          |            |           | <b>2-Position — 60° Throw — Black Knob</b>        |                  |                     |                |                                   |                     |                  |                     |                                  |  |
| —        | M          | M         | 2   | <u>E22XBF61</u>  |                     | <u>E22XF61</u> |                                   | <u>EM22XF61</u>     |                  |                     |                                  |  |
| M        | —          | M         | 2   | <u>E22XB561</u>  |                     | <u>E22X561</u> |                                   | <u>EM22X561</u>     |                  |                     |                                  |  |
| —        | M          | S         | 2   | <u>E22XBE61</u>  |                     | <u>E22XE61</u> |                                   | <u>EM22XE61</u>     |                  |                     |                                  |  |
| M        | —          | S         | 2   | <u>E22XB661</u>  |                     | <u>E22X661</u> |                                   | <u>EM22X661</u>     |                  |                     |                                  |  |
|          |            |           | <b>3-Position — 60° Throw — Black Knob</b>        |                  |                     |                |                                   |                     |                  |                     |                                  |  |
| M        | M          | M         | 1   | <u>E22XBG61</u>  |                     | <u>E22XG61</u> |                                   | <u>EM22XG61</u>     |                  |                     |                                  |  |
| M        | M          | M         | 2   | <u>E22XBH61</u>  |                     | <u>E22XH61</u> |                                   | <u>EM22XH61</u>     |                  |                     |                                  |  |
| S        | M          | M         | 1   | <u>E22XBJ61</u>  |                     | <u>E22XJ61</u> |                                   | <u>EM22XJ61</u>     |                  |                     |                                  |  |
| S        | M          | M         | 2   | <u>E22XBK61</u>  |                     | <u>E22XK61</u> |                                   | <u>EM22XK61</u>     |                  |                     |                                  |  |
| S        | M          | S         | 1   | <u>E22XBL61</u>  |                     | <u>E22XL61</u> |                                   | <u>EM22XL61</u>     |                  |                     |                                  |  |
| S        | M          | S         | 2   | <u>E22XBM61</u>  |                     | <u>E22XM61</u> |                                   | <u>EM22XM61</u>     |                  |                     |                                  |  |
| M        | M          | S         | 1   | <u>E22XBN61</u>  |                     | <u>E22XN61</u> |                                   | <u>EM22XN61</u>     |                  |                     |                                  |  |
| M        | M          | S         | 2   | <u>E22XBP61</u>  |                     | <u>E22XP61</u> |                                   | <u>EM22XP61</u>     |                  |                     |                                  |  |

① Listed selector switches are supplied as standard with Black levers or knobs. To select an alternate color, change the last digit (underlined) in the listed Catalog Number using Code Number from following table. Example: E22VE62 — Two-Position Selector Switch with Red Lever.

| Color | Code | Color | Code | Color | Code | Color  | Code | Color | Code | Color | Code | Color | Code | Color  | Code |
|-------|------|-------|------|-------|------|--------|------|-------|------|-------|------|-------|------|--------|------|
| Black | 1    | Red   | 2    | Green | 3    | Yellow | 4    | White | 5    | Blue  | 6    | Gray  | 7    | Orange | 8    |

**Note:** For Rear of Panel Extensions, see Table 47-128 on Page 47-94.

**Ordering Example** — A complete Non-illuminated Selector Switch consists of the following:

