


## Socket Converter

1 to 2 sockets and 2 to 3 sockets



**776-8431**

1 to 2 Socket Converter  
Converts a single socket  
to a double  
Replaces existing single socket



**776-8435**

2 to 3 Socket Converter  
Converts a double socket  
to a triple socket