5 Port Solenoid Valve W

Metal Seal / Rubber Seal Power consumption:



(High pressure type, High speed response type) **Compact, High Flow**

0

		Value width	Flow char	Culindor	
	Series	(mm)	Metal seal C [dm ³ /(s·bar)]	Rubber seal C [dm ³ /(s·bar)]	size
ted	VQZ1□2□	10	0.54	0.71	to ø50
V	VQZ2□2□	15	1.4	1.6	to ø80
Bod	VQZ3□2□	18	2.4	3.2	to ø100
nted	VQZ1□5□	10	0.70	1.3	to ø63
nom	VQZ2□5□	15	1.9	2.3	to ø100
Base	VQZ3□5□	18	3.0	4.6	to ø100

* Flow characteristics: 4/2→5/3 (A/B→R1/R2)







Metal Seal / Rubber Seal

5 Port Solenoid Valve Series VQZ1000/2000/3000



Series	Response speed	Service life	Accuracy
VQZ1000	17 ms	200	
VQZ2000	18 ms	million	±2 ms
VQZ3000	21 ms	cycles	

* Metal seal, single solenoid with light/surge voltage suppressor, according to SMC life test conditions.

Body ported

• Both 3 and 5 port valves can be mounted on the same manifold.



• DIN rail mounting is

available.

Base mounted

Built-in one-touch fittings for easier piping

Easy replacement of clip type one-touch fitting.



Enclosure IP65 compliant (DIN terminal, Common exhaust) Choice of metal or rubber seal for main valve construction

Cylinder Speed Chart

Body Ported

Use as a guide for selection. Please confirm the actual conditions with SMC Sizing Program.

							Bore	size					
Series	Average speed (mm/s)	Series CJ Pressure Load facto Stroke 60	2 0.5 MPa or 50% mm		Series CM Pressure 0 Load facto Stroke 300	2 0.5 MPa r 50% 0 mm			Series MB Pressure (Load facto Stroke 500	, CA1).5 MPa or 50%) mm			
		ø6	ø10	ø16	ø20	ø25	ø32	ø40	ø40	ø50	ø63	ø80	ø100
	800 700 600 500										Perpendic Horizonta	cular, upward I actuation	actuation
VQZ1121-C6	400 300 200 100 0												
VQZ2121-C6	800 700 600 500 400 300 200 100 0												
VQZ3121-C6	800 700 600 500 400 300 200 100												

Base Mounted

Bore size													
Series	Average speed (mm/s)	Series CJ2 Pressure (Load facto Stroke 60	2 0.5 MPa or 50% mm		Series CM Pressure 0 Load facto Stroke 300	2).5 MPa r 50%) mm			Series MB Pressure (Load facto Stroke 500	, CA1).5 MPa or 50%) mm	_		
		ø6	ø10	ø16	ø20	ø25	ø32	ø40	ø40	ø50	ø63	ø80	ø100
VQZ1151-01	800 700 600 500 400 300 200 100 0										Perpendic Horizonta	ular, upward I actuation	
VQZ2151-02	800 700 600 500 400 300 200 100 0												
VQZ3151-03	900 800 700 600 500 400 300 200 100 0												

* It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open. * The average velocity of the cylinder is what the stroke is divided by the total stroke time.

* Load factor: ((Load weight x 9.8)/Theoretical output) x 100%

Conditions

Ĵ

Body	ported	Series CJ2	Series CM2	Series MB, CA1		
	Tube x Length					
VQZ1121-C6	Speed controller		AS2051F-06			
	Silencer	AN120-M5				
	Tube x Length	T0604 x 1m				
VQZ2121-C6	Speed controller		AS3001F-06			
	Silencer		INA-25-46			
	Tube x Length	T1075 x 1m				
VQZ3121-C6	Speed controller	AS4001F-10				
	Silencer	AN101-01				

Base	mounted	Series CJ2	Series CM2	Series MB, CA1		
	Tube x Length		T0604 x 1 m			
VQZ1151-01	Speed controller		AS3001F-06			
	Silencer	AN110-01				
	Tube x Length	T0604 x 1 m	T0806 x 1 m			
VQZ2151-02	Speed controller	AS3001F-06 AS3001F-08				
	Silencer		AN200-02			
	Tube x Length	T0604 x 1 m	T1075 x 1 m	T1209 x 1 m		
VQZ3151-03	Speed controller	AS3001F-06	AS4001F-10	AS4001F-12		
	Silencer	AN300-03				



Series VQZ Model Selection



Front matter 2

SMC



Manifold

Body Ported –

			Piping specific	Applicable		
Series	Base model	Piping	Poi	t size	solenoid	stations
		direction	1(P), 3·5(R)	4(A), 2(B)	valve	
VQZ1000	VV5QZ12-□□□	Тор	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡20 VQZ1⊡21	2 to 20 stations
VQZ2000	VV5QZ22-□□□	Тор	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2⊟20 VQZ2⊟21	2 to 20 stations
VQZ3000	VV5QZ32-□□□	Тор	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3⊟20 VQZ3⊟21	2 to 20 stations

Serial Transmission — P.23 System



- P.42

- P.13



Base Mounted -

			Piping specific	Applicable	Applicable		
Series	Base model	Piping	Poi	t size	solenoid	Applicable	
		direction	1(P), 3·5(R)	4(A), 2(B)	valve	otationio	
VQZ1000	VV5QZ15-□□□	Side	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡50 VQZ1⊡51	2 to 20 stations	
VQZ2000	VV5QZ25-□□□	Side	Rc 1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2⊟50 VQZ2⊟51	2 to 20 stations	
VQZ3000	VV5QZ35-□□□	Side	1(P) port Rc 3/8 3 ⋅ 5(R) port Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3⊡50 VQZ3⊡51	2 to 20 stations	

Serial Transmission — P.56 System



Series VQZ

Manifold Options



Base Mounted



Front matter 4

Body Ported

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Single Unit (c [Option]



SMC



Specifications

	Туре		Metal seal	Rubber seal	
Fluid			Air, Inert gas		
Max. operating pro	essure (MPa)		0.7 (High pressure type: 1.0)	0.7	
Min operating	2 position	Single	0.1	0.15	
nressure (MPa)	2 position	Double	VQZ3000, 3 position only	0.1	
pressure (init a)	3 position		0.15	0.2	
Ambient and fluid temperature (°C)			-10 to 50 (N	No freezing)	
Max. operating	2 position single, double 3 position		20	5	
frequency (Hz)			10	3	
Manual override			Non-locking push type, Lo	ocking type (Tool required)	
Pilot exhaust met	nod		Individual exhaust		
Lubrication			Not required		
Mounting orientat	ion		Single: Free Double, 3 position: Main valve must be horizontal.	Free	
Impact/Vibration resistance (m/s ²) Note 1)			150/30		
Enclosure*			Dustproof (DIN terminal: IP65 Note 2)		
* Based on IEC60529 Note 1) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction					

lve and armature in both e energized states every once for each condition. (Value in the initial state) Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state) Note 2) When IP65 compliant DIN terminals are selected: VQZ²₃□21□-□Y□□W1-□-□

Solenoid Specifications

			Grommet (G)	M-type plug connector (M)	
Electrical entry			L-type plug connector (L)	DIN terminal (Y)	
			G, L, M	Y	
Coil rated voltage		DC	24,	12	
(V)	AC 50/60 Hz		100, 110,	200, 220*	
Allowable voltage fluctuation			±10% of ra	ted voltage	
Power	D C	Standard	0.35 [(With light: 0.4 (DIN	I terminal with light: 0.45)]	
consumption (W)	DC	High speed response, high pressure	0.9 [(With light: 0.95 (DI	N terminal with light: 1.0)]	
		100V	0.78 (With light: 0.81)	0.78 (With light: 0.87)	
		110V	0.86 (With light: 0.89)	0.86 (With light: 0.87)	
Apparent power	1	[115V]	[0.94 (With light: 0.97)]	[0.94 (With light: 1.07)]	
(VA)*	AC	200V	1.18 (With light: 1.22)	1.15 (With light: 1.30)	
		220V	1.30 (With light: 1.34)	1.27 (With light: 1.46)	
		[230V]	[1.42 (With light: 1.46)]	[1.39 (With light: 1.60)]	
Surge voltage sup	Surge voltage suppressor			istor	
Indicator light			LED (Neon light when AC with DIN terminal)		
 In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. * For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage. 					

Flow characteristics Response time (ms) Note 1) Note 2 Weight Series Configuration Model 1→4/2 (P-→A/B) 4/2→5/3 (A/B→EA/EB) Standard: response: 0.9 W AC Cv 0.35 W 0.9 W (g) C [dm3/(s•bar)] Cv C [dm3/(s•bar)] b b VQZ1120 Metal seal 0.54 0.13 17 or less 12 or less 15 or less 29 or less 0.20 0.54 0.26 0.13 45 Single 2 VQZ1121 Rubber seal 0.90 0.40 0.26 0.71 0.40 0.19 17 or less 12 or less 34 or less positior VQZ1220 Metal seal 0.54 0.20 0.13 0.54 0.26 0.13 10 or less 10 or less 13 or less 13 or less Double 62 VQZ1221 Rubber seal 0.90 0.40 0.26 0.71 0.40 0.19 10 or less 10 or less 13 or less VQZ1000 VQZ1320 Metal seal 0.55 0.29 0.13 0.50 0.25 0.08 25 or less 20 or less 26 or less 40 or less Closed center VQZ1321 Rubber seal 0.87 0.38 0.23 0.68 0.39 0.18 30 or less 25 or less 47 or less 3 VQZ1420 65 Metal seal 0.55 0.28 0.13 0.54 0.26 0.13 25 or less 20 or less 26 or less 40 or less position Exhaust center VQZ1421 Rubber seal 0.87 0.38 0.23 0.71 0.40 0.19 30 or less 25 or less 47 or less Pressure center VQZ1521 Rubber seal 0.91 0.41 0.26 0.68 0.39 0.18 30 or less 25 or less 47 or less Metal seal VQZ2120 1.2 0.21 0.30 1.4 0.20 0.32 18 or less 14 or less 18 or less 34 or less Single 65 2 VQZ2121 Rubber seal 17 0.39 0.45 1.6 0.35 0.44 20 or less 15 or less 36 or less positior Metal seal VQZ2220 1.2 0.21 0.30 1.4 0.20 0.32 10 or less 10 or less 13 or less 13 or less Double 84 Rubber seal VQZ2221 1.7 0.39 0.45 1.6 0.35 0.44 12 or less 12 or less 15 or less Metal seal VQZ2320 1.1 0.21 0.26 1.1 0.24 0.26 28 or less 23 or less 30 or less 44 or less VQZ2000 Closed center Rubber seal VQZ2321 14 0.33 0.35 14 0.37 0.36 30 or less 25 or less 47 or less 3 Metal seal VQZ2420 1.1 0.23 0.28 1.4 0.20 0.32 28 or less 23 or less 30 or less 44 or less Exhaust center 91 positior Rubber seal VQZ2421 0.33 0.35 0.35 0.44 30 or less 25 or less 47 or less 1.4 1.6 Metal seal VQZ2520 1.3 0.28 0.34 1.2 0.27 0.30 28 or less 23 or less 30 or less 44 or less Pressure center Rubber seal VQZ2521 0.34 0.44 1.4 0.37 0.36 30 or less 25 or less 47 or less 17 2.4 Metal seal VQZ3120 0.23 0.56 0.19 0.54 21 or less 17 or less 22 or less 34 or less 2.4 Single 108 2 Rubber seal VQZ3121 0.34 0.79 3.2 0.81 3.1 0.38 33 or less 25 or less 57 or less positior Metal seal VQZ3220 2.4 0.23 0.56 2.4 0.19 0.54 10 or less 10 or less 13 or less 13 or less Double 125 VQZ3221 0.79 Rubber seal 3.1 0.34 3.2 0.38 0.81 15 or less 15 or less 20 or less VQZ3320 0.19 0.54 2.1 0.21 0.54 33 or less 25 or less 33 or less 53 or less Metal seal 2.3 VQZ3000 Closed center VQZ3321 0.66 2.4 Rubber seal 2.7 0.30 0.33 0.62 35 or less 30 or less 59 or less 3 Metal seal VQZ3420 2.3 0.19 0.54 2.4 0.19 0.54 33 or less 25 or less 33 or less 53 or less Exhaust center 136 positior VQZ3421 Rubber seal 2.7 0.30 0.66 3.2 0.38 0.81 35 or less 30 or less 59 or less Metal seal VQZ3520 2.5 0.25 0.60 2.1 0.18 0.47 33 or less 25 or less 33 or less 53 or less Pressure center Rubber seal VQZ3521 3.2 0.38 0.82 2.4 0.33 0.62 35 or less 30 or less 59 or less

Note 1) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)

Response time values will change depending on pressure and air quality. Note 2) Weight for threaded connection



Options

High speed response type

High pressure type (Metal seal type only) External pilot type (Except VQZ1000)* * For details on external pilot type, refer to page 21.

> Made to Order (For details, refer to page 63.)

Symbol	Description
X30	Pilot valve common exhaust
X90	Main valve fluoro-rubber
X113	All fluoro-rubber

Flow Characteristics

2



Body Ported Series VQZ1000/2000/3000

Construction: VQZ1000/2000/3000



••••										
No.	Description	Material	Note							
1	Body	Aluminum die-casted								
•	Spool, Sleeve	Stainless steel	Metal seal							
2	Spool valve	Aluminum/HNBR	Rubber seal							
3	Piston	Resin								
4	Pilot valve assembly	_								

Note) For "How to Order Pilot Valve Assembly", refer to page 22.



Body Ported Series VQZ1000/2000/3000

Dimensions: VQZ1000

2 Position Double

Grommet (G): VQZ122 ⁰₁-□G□1-C3, C4, C6



Dimensions: VQZ1000

3 Position Closed Center/Exhaust Center/Pressure Center (Except Metal seal type)

Grommet (G): VQZ1 $\frac{3}{4}$ 2 $\frac{0}{1}$ - \Box G \Box 1-C3, C4, C6



Body Ported Series VQZ1000/2000/3000











Body Ported Series VQZ1000/2000/3000

Dimensions: VQZ3000



SMC

L-type plug connector (L): VQZ322 ⁰₁ (R)-□L□1-C6, C8, C10

DIN terminal (Y): VQZ322 ⁰/₁ (R)-□Y□1-C6, C8, C10



M-type plug connector (M): VQZ322⁰/₁ (R)-□M□1-C6, C8, C10







Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ3000



SMC



M-type plug connector (M): VQZ3 $\frac{3}{5}$ 2 $\frac{9}{1}$ (R)- \Box M \Box 1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G).



Unless otherwise indicated, dimensions are the same as Grommet (G).

Body Ported

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Manifold Connector Kit (C [Option]



Manifold Specifications



		Pip	ing spec	ifications	Applicable	Applicable	Manifold
Series	Base model	Piping direction	1(P) 3/5(B)	Port size	solenoid valve	stations	base weight (g)
VQZ1000	VV5QZ12-□□□	Тор	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡20 VQZ1⊡21	2 to 20 stations	2 stations: 64 Addition per station: 18
VQZ2000	VV5QZ22-□□□	Тор	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2⊡20 VQZ2⊡21	2 to 20 stations	2 stations: 86 Addition per station: 26
VQZ3000	VV5QZ32-□□□	Тор	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3⊟20 VQZ3⊟21	2 to 20 stations	2 stations: 181 Addition per station: 53

How to Order Manifold Assembly (Example)



Body Ported Series VQZ1000/2000/3000

Dimensions: VQZ1000

VV5QZ12- Stations C



Dimensions: VQZ2000





16.5

17.5

15.5

18.5

16.5

15.5

L4

19.5

20.5

Body Ported Series VQZ1000/2000/3000



Dimensions: VQZ3000

L4

L5

18.5

15.5

18.5



20.5

17.5

20.5

16.5

19.5

17.5

16.5

Manifold Options

Blanking plate assembly VVQZ1000-10A-2 (for VQZ1000) VVQZ2000-10A-2 (for VQZ2000) VVQZ3000-10A-2 (for VQZ3000)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



DIN rail AXT100-DR-

* As for □, enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail.

Insert "D" at the end of the manifold part number. The DIN rail is approximately 30 mm longer than the length of manifold.

L	Dim	en	sio
-		CII	3101

L Dime	nsio	on															L =	= 12.	5n +	10.5
No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

đ

Blanking plug KQ2P-23 KQ2P-04 KQ2P-06 KQ2P-08 **KQ2P-10**





Dimensions

Applicable fitting size ød	Model	Α	L	D
3.2	KQ2P-23	16	31.5	3.2
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8
8	KQ2P-08	20.5	39	10
10	KQ2P-10	22	43	12

Silencer (for manifold EXH port)

Silencer is installed in the manifold EXH port.





Model Silencer part n VQZ1000 AN110-01 VQZ2000 AN110-01 VQZ3000 AN200-02				
Model	Silencer part no.			
VQZ1000	AN110-01			
VQZ2000	AN110-01			
VQZ3000	AN200-02			

Port plug VVQZ100-CP (for VQZ1000/2000) VVQZ2000-CP (for VQZ3000)

Used to block a cylinder port when changing 5 port valves into 3 port valves, etc.



Body Ported Series VQZ1000/2000/3000

Manifold Options



Manifold Options

Perfect block (Separated): For VQZ2000/3000 VQ2000-FPG-

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the perfect block with a built-in pilot type perfect valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in a the middle or maintain its position for a long time. The combination of a 2 position single or double solenoid with a perfect block will prevent the cylinder from "dropping" at stroke end when residual supply pressure is released.

Specifications

Ē₽

H **H**

01

02

C6

20

C8

Manifold

20.5

58

(59.5)

Maximum operating pressure	0.8 MPa
Minimum operating pressure	0.15 MPa
Ambient and fluid temperature	–5 to 50°C
Flow characteristics: C	3.0 dm ³ /(s·bar)
Max. operating frequency	180 c.p.m

<Check valve operating principle>

torque for mounting a

bracket for the perfect

block



<Ordering Example> VVQ2000-FPG-06 ···· 6 stations of manifold * VQ2000-FPG-C6C6-D, 3 sets Perfect

* VQ2000-FPG-C8C8-D, 3 sets block

- Book, proper upfiltering torque for screws is as shown at the right.
 Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.
 If exhaust side of perfect block is narrowed down too much, intermediate stopping accuracy will be decreased.

Rc 1/8

7 to 9





External Pilot Specification (Except VQZ1000)

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.2 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.



Inch size one-touch fittings and NPT, NPTF and G thread are available.

Entry is the same as

standard products.



Note) The pilot exhaust IP65 valves is common with main valve exhaust.

SMC

(The standard valve has an individual exhaust for the pilot valve.)

21

Series VQZ Body Ported **Replacement Parts**

One-touch Fitting Assembly (for Cylinder port)

Fitting size Model	СЗ	C4	C6	C8	C10
VQZ1000/2000	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	_
VQZ3000	—	—	VVQ1000-51A-C6	VVQ1000-51A-C8	VVQ1000-51A-C10

Note) Purchasing order is available in units of 10 pieces.



How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Example) In case of 2000 mm of lead wire

DC	AC
VQZ1120-5LO1-M5	VQZ1120-1LO1-
SY100-30-4A-20	SY100-30-1A-20

CDIN terminal type (Applicable to the VQZ2000/3000)

SY100-30-	4A-20	SY100-30-1A-20										
<gaske< th=""><th>et and scr</th><th>ew assembly:</th><th>></th><th></th><th>V115</th><th>5</th><th>_</th><th>5</th><th>Y_X110</th><th></th></gaske<>	et and scr	ew assembly:	>		V115	5	_	5	Y_X110			
		Part no.			Funct	ion 🖣						
VQZ1	000	VQZ1000-GS-2	Symbol	Specifica	ations DC	AC						
VQZ2	000	VQZ2000-GS-2	Nil	Standard	(0.35 W)	0	-					
VQZ3	000	VQZ3000-GS-2	B Note)	High speed read	sponse type	—	-					
Note) Above part nui Each unit has	mber consists of 10 ur one gasket and two	nits. K Note)	High pressure (Metal seal type	type (0.9 W) e only)	_						
	screws. Purch units of 10 pie	asing order is available ces.	e in \mathbf{P}^{No}	te) Option								
	ê				Coil voltage	•			Electrica	l entry		
		8	1	100 VAC (5 200 VAC (5	0/60 Hz) 0/60 Hz)	_	Symbol		Electrical entry	Light/surge voltage suppressor		
	8		3	110 VAC [1	15 VAC] (50/60 Hz)		Y	DIN term	inal	None		
			4	220 VAC [2	30 VAC] (50/60 Hz)		YO	DIN term	inal without connector	None		
	ĥ		5	24 VDC			YZ	DIN termir	al with light/surge voltage suppressor	Yes		
			6	12 VDC			YS	DIN termi (DC spec	inal with surge voltage suppressor ification)	Yes (With		
		69					YOS	DIN term	inal with surge voltage suppressor, onnector (DC specification)	light)		
<brack< td=""><td>et asseml</td><td>oly></td><td></td><td></td><td></td><td></td><td></td><td>Note) For A</td><td>C voltage valves there is no "S" option</td><td>. It is</td></brack<>	et asseml	oly>						Note) For A	C voltage valves there is no "S" option	. It is		
		Part no.	Tightening torq	ue (N•m) ^{Note)}				alread	y built-in to the rectifier circuit.			
VO71000	Metal seal	VQZ1000V-FB-M	0.0.1-	0.00								
VQZ1000	Rubber seal	VQZ1000V-FB-R	0.2 to	0.20				•				
VQ	Z2000	VQZ2000-FB	0.25 to	0.35				?\ Cai	ution			
VQ	Z3000	VQZ3000-FB	0.25 to	0.35								
	 When adding plate and bra to the bracke that it does n 	g a bracket assembly I cket at the tightening t assembly. Place the ot get lost.	ater, remove the e torque shown in the spring inside the e	end plate screws ne table, using th end plate in its or	and fasten the end le screws attached riginal position so		w us cc (G	Se cautio Se cautio Sonvert to Grommet,	a V115 (DIN terminal) from a L-type, M-type), or vice vers	embly, co V111 a.		

22



(Grommet, L-type, M-type), or vice versa.

Series VQZ

For details of "Gateway System Serial Transmission System, Series EX510", refer to CAT.E02-22B catalog.

Gateway System Serial Transmission System Series EX510

• All wires can be plugged into the connector units.



EX510 Gateway System Serial Transmission System Series VQZ1000/2000/3000 Body Ported Manifold

CE [Option]



How to Order Valve Manifold Assembly (Example)



SI Unit Part No.

Symbol	SI unit spec.	SI unit part no.
Nil	NPN output (+COM.)	EX510-S001
Ν	PNP output (-COM.)	EX510-S101

For details of "Gateway System Serial Transmission System, Series EX510", refer to CAT.E02-22B catalog.

EX510 Gateway System Serial Transmission System Series VQZ1000/2000/3000

How to Order Valve



	(· · · · · · · · · · · · · · · · · · ·
Symbol	Description
X30	Pilot valve common exhaust
X90	Main valve fluoro-rubber
X113	All fluoro-rubber

Dimensions: VQZ1000-SA



Dimens	Dimensions Max													Max. 16	stations
n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	123	123	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248
L2	112.5	112.5	112.5	112.5	112.5	125	137.5	150	162.5	175	187.5	200	212.5	225	237.5
L3	88	88	88	88	88	100	112	124	136	148	160	172	184	196	208
L4	17.5	17.5	17.5	17.5	17.5	18	18.5	18.5	19	19	19	19.5	19.5	20	20
L5	80	80	80	80	80	92	104	116	128	140	152	164	176	188	200

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.

Dimensions: VQZ2000-SA



in type plug connector (in

The dashed lines indicate the DIN rail mounting [-D].

Unless otherwise indicated, dimensions are the same as L-type plug connector (L).
[]: AC

Dimensions Max. 16 sta									stations						
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	135.5	135.5	135.5	135.5	160.5	173	185.5	210.5	223	248	260.5	273	298	310.5	323
L2	125	125	125	125	150	162.5	175	200	212.5	237.5	250	262.5	287.5	300	312.5
L3	104	104	104	104	121	138	155	172	189	206	223	240	257	274	291
L4	16	16	16	16	20	17.5	15.5	19.5	17	21	19	16.5	20.5	18.5	16
L5	94	94	94	94	111	128	145	162	179	196	213	230	247	264	281

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.

Dimensions: VQZ3000-SA



Dimensions Max. 16 station										stations					
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	148	173	185.5	210.5	223	248	273	285.5	310.5	323	348	373	385.5
L2	112.5	112.5	137.5	162.5	175	200	212.5	237.5	262.5	275	300	312.5	337.5	362.5	375
L3	92	92	112	132	152	172	192	212	232	252	272	292	312	332	352
L4	15.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17
L5	70	70	90	110	130	150	170	190	210	230	250	170	290	310	330

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.

Manifold Options

Connector assembly

Single solenoid (SY3000-37-81A-D-N)

Double solenoid (SY3000-37-81A-□-□)



Connector Assembly Part No. (for a manifold with 8 stations or less with an unspecified layout) Bar Stock Type

Model	Part no.	Connector mounting position				
	SY3000-37-81A-3-N	Single: for 1 to 4 stations				
V/VE0712	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations				
VVJQZIZ	SY3000-37-81A-2-N	Single: for 5 to 8 stations				
	SY3000-37-81A-3-6	Double/3 position: for 5 to 8 stations				
V/VE O7 00	SY3000-37-81A-3-N	Single: for 1 to 8 stations				
VV5QZZZ	SY3000-37-81A-3-6	Double/3 position: for 1 to 8 stations				
	SY3000-37-81A-3-N	Single: for 1 to 4 stations				
	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations				
VV5QZ32	SY3000-37-81A-4-N	Single: for 5 to 8 stations				
	SY3000-37-81A-4-7	Double/3 position: for 5 to 8 stations				

Note) There are no part nos. on the connectors of connector assemblies.

Connector assembly SY3000-37-80A-



Housing (1 set: 8 pieces) SY3000-44-3A



Connector Assembly Part No. (for a manifold with a specified layout)

Model	Assembly part no.	Connector mounting position				
	SY3000-37-80A-3	A side	For 1 to 8 stations			
V/VEO712	SY3000-37-80A-6	B side				
VVJQZIZ	SY3000-37-80A-4	A side	For 0 to 16 stations			
	SY3000-37-80A-7	B side	FOI 9 10 16 Stations			
	SY3000-37-80A-3	A side	For 1 to 8 stations			
V/VEO700	SY3000-37-80A-6	B side				
VV5QZZZ	SY3000-37-80A-7	A side	For 0 to 10 stations			
	SY3000-37-80A-9	B side	FOR 9 10 16 STATIONS			
	SY3000-37-80A-4	A side	For 1 to 8 stations			
V/VEO722	SY3000-37-80A-7	B side				
V V JQZ3Z	SY3000-37-80A-8	A side				
	SY3000-37-80A-11	FOI 9 IO 16 STATIONS				

Note 1) Since these connector assemblies are used when adding stations or for maintenance, there are no part nos. on them.

Note 2) After inserting the connector assembly into the housing, slightly pull the lead wire to make sure it does not pull out. Do not reuse the lead wire once it has been inserted.

Note 3) Please note that the wires are longer than the actual wiring distance.



Base Mounted

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Single Unit (c [Option]



Use standard (DC) specification for continuous duty.

30

6

Note) For sub-plate part no., refer to page 55.


Specifications

┢

	Type		Metal seal	Rubber seal					
Fluid			Air, Inert gas						
Max. operating pre	essure (MPa)		0.7 (High pressure type: 1.0)	0.7					
Min operating	2 position	Single	0.1	0.15					
min. operating	2 position	Double	VQZ3000, 3 position only	0.1					
pressure (init a)	3 position		0.15	0.2					
Ambient and fluid	temperature	(°C)	-10 to 50 (N	lo freezing)					
Max. operating	2 position	single, double	20	5					
frequency (Hz)	3 position		10	3					
Manual override			Non-locking push type, Lo	cking type (Tool required)					
Pilot exhaust meth	nod		Individual exhaust						
Lubrication			Not required						
Mounting orientati	on		Single: Free Double, 3 position: Main valve must be horizontal.	Free					
Impact/Vibration re	esistance (m	/s ²) Note 1)	150	/30					
Enclosure*			Dustproof (DIN terminal: IP65 Note 2)						
* Based on IEC60529 Note 1) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-									

 Note 1) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Value in the initial state)

 Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state)

 Note 2) When IP65 compliant DIN terminals are selected: VQZ₃² □51□-□Y□W1-□-□

0.35 0.97 35 or less 30 or less

Solenoid Specifications

			Grommet (G)	M-type plug connector (M)					
Electrical entry			L-type plug connector (L)	DIN terminal (Y)					
			G, L, M	Y					
Coil rated voltage		DC	24	, 12					
(V)		AC 50/60 Hz	100, 110,	200, 220 [*]					
Allowable voltage	fluct	uation	±10% of ra	ited voltage					
Power	-	Standard	0.35 [(With light: 0.4 (DIN	terminal with light: 0.45)]					
consumption (W)	DC	High speed response, high pressure	0.9 [(With light: 0.95 (DIN terminal with light: 1.0)]						
		100V	0.78 (With light: 0.81)	0.78 (With light: 0.87)					
		110V	0.86 (With light: 0.89)	0.86 (With light: 0.87)					
Apparent power		[115V]	[0.94 (With light: 0.97)]	[0.94 (With light: 1.07)]					
(VA)*	AC	200V	1.18 (With light: 1.22)	1.15 (With light: 1.30)					
		220V	1.30 (With light: 1.34)	1.27 (With light: 1.46)					
		[230V]	[1.42 (With light: 1.46)]	[1.39 (With light: 1.60)]					
Surge voltage sup	press	sor	Var	istor					
Indicator light			LED (Neon light when AC with DIN terminal)						
 In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. * For 115 VAC and 230 VAC, the allowable voltage is –15% to +5% of rated voltage. 									

Options

High speed response type
High pressure type (Metal seal type only)

ringir procouro typo	(motal ooal type only)
External pilot type*	

* For details on external pilot type, refer to page 54.

ladë 1 Made to Order Ordet (For details, refer to page 63.)

Symbol	Description
X30	Pilot valve common exhaust
X90	Main valve fluoro-rubber
X113	All fluoro-rubber

Flow (

	arac	lensucs		0											
						F	low cha	racteristics			Best	oonse tin	ne (ms) ^N	lote 1)	Note 2)
Series	c	Configuration	Mode	Model		$1 \rightarrow 4/2 (P \rightarrow A/B)$ $4/2 \rightarrow 5/3 (A/B \rightarrow$					Standard:	High speed response: High pressure:		AC	Weight
					C [dm ³ /(s•bar)]	b	Cv	C [dm ³ /(s•bar)]	b	Cv	0.35 W	0.9 W	0.9 W	70	(g)
		Single	Metal seal	VQZ1150	0.70	0.21	0.17	0.70	0.21	0.17	17 or less	12 or less	15 or less	29 or less	40
	2	Single	Rubber seal	VQZ1151	1.2	0.35	0.30	1.3	0.24	0.32	17 or less	12 or less	-	34 or less	40
	position	Doublo	Metal seal	VQZ1250	0.70	0.21	0.17	0.70	0.21	0.17	10 or less	10 or less	13 or less	13 or less	57
		Double	Rubber seal	VQZ1251	1.2	0.35	0.30	1.3	0.24	0.32	10 or less	10 or less	-	13 or less	57
VQZ1000		Closed conter	Metal seal	VQZ1350	0.56	0.20	0.13	0.57	0.22	0.14	25 or less	20 or less	26 or less	40 or less	
	Closed center	Closed certier	Rubber seal	VQZ1351	1.1	0.33	0.27	1.0	0.38	0.27	30 or less	25 or less	-	47 or less	
	position	Exhaust contor	Metal seal	VQZ1450	0.56	0.20	0.13	0.70	0.21	0.17	25 or less	20 or less	26 or less	40 or less	60
	Exhaust center	Rubber seal	VQZ1451	1.1	0.33	0.27	1.3	0.24	0.32	30 or less	25 or less	-	47 or less		
		Pressure center	Rubber seal	VQZ1551	1.4	0.20	0.34	1.0	0.38	0.27	30 or less	25 or less	-	47 or less	
		Cingle	Metal seal	VQZ2150	1.6	0.13	0.36	1.9	0.16	0.40	18 or less	14 or less	18 or less	34 or less	61
	2 Single	Rubber seal	VQZ2151	2.0	0.35	0.51	2.3	0.29	0.53	20 or less	15 or less	-	36 or less	01	
	position	Daubla	Metal seal	VQZ2250	1.6	0.13	0.36	1.9	0.16	0.40	10 or less	10 or less	13 or less	13 or less	00
		Double	Rubber seal	VQZ2251	2.0	0.35	0.51	2.3	0.29	0.53	12 or less	12 or less	-	15 or less	00
VO7000		Closed contex	Metal seal	VQZ2350	1.5	0.16	0.35	1.3	0.26	0.32	28 or less	23 or less	30 or less	44 or less	
VQZ2000		Closed certier	Rubber seal	VQZ2351	1.7	0.27	0.39	1.7	0.28	0.39	30 or less	25 or less	-	47 or less	
	3	Exhaust center	Metal seal	VQZ2450	1.5	0.16	0.35	1.9	0.16	0.40	28 or less	23 or less	30 or less	44 or less	07
	position		Rubber seal	VQZ2451	1.7	0.27	0.39	2.3	0.29	0.53	30 or less	25 or less	-	47 or less	87
		Duran suran a surata u	Metal seal	VQZ2550	1.8	0.13	0.39	1.5	0.26	0.36	28 or less	23 or less	30 or less	44 or less	
		Pressure center	Rubber seal	VQZ2551	2.0	0.35	0.50	1.7	0.28	0.39	30 or less	25 or less	-	47 or less	
		0. 1	Metal seal	VQZ3150	2.6	0.12	0.60	3.0	0.15	0.74	21 or less	17 or less	22 or less	34 or less	
	2	Single	Rubber seal	VQZ3151	3.9	0.29	1.0	4.6	0.26	1.2	33 or less	25 or less	-	57 or less	93
	position	Daulala	Metal seal	VQZ3250	2.6	0.12	0.60	3.0	0.15	0.74	10 or less	10 or less	13 or less	13 or less	110
		Double	Rubber seal	VQZ3251	3.9	0.29	1.0	4.6	0.26	1.2	15 or less	15 or less	-	20 or less	110
VO73000	072000		Metal seal	VQZ3350	2.4	0.12	0.58	2.8	0.16	0.65	33 or less	25 or less	33 or less	53 or less	
V GZ 3000		Ciosea center	Rubber seal	VQZ3351	3.1	0.33	0.82	3.6	0.35	0.97	35 or less	30 or less	—	59 or less	
	3	Exhaust contain	Metal seal	VQZ3450	2.4	0.12	0.58	3.0	0.15	0.74	33 or less	25 or less	33 or less	53 or less	101
	position	Exhaust center	Rubber seal	VQZ3451	3.9	0.33	0.82	4.6	0.26	1.2	35 or less	30 or less	_	59 or less	121
		Dressure conter	Metal seal	VQZ3550	3.0	0.12	0.69	2.9	0.16	0.65	33 or less	25 or less	33 or less	53 or less	
	Pressure center								1						

Rubber seal VQZ3551 4.4 Note 1) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)

Response time values will change depending on pressure and air quality. The values at the time of ON are given for double types.

Note 2) Weight without sub-plate

Pressure center



0.27 1.1

3.6

59 or less

Construction: VQZ1000/2000/3000



Component Parts

No.	Description	Material	Note
1	Body	Aluminum die-casted	
0	Spool, Sleeve	Stainless steel	Metal seal
2	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) For "How to Order Pilot Valve Assembly", refer to page 55.

Dimensions: VQZ1000

2 Position Single/3 Port for Mixture Mounting



L-type plug connector (L): VQZ1 $\frac{1}{9}5^{0}_{1}(R)$ -□L□1-01



M-type plug connector (M): VQZ1 $\frac{1}{9}5^{0}_{1}$ (R)- \Box M \Box 1-01



Unless otherwise indicated, dimensions are the same as Grommet (G).
[]: AC

Dimensions: VQZ1000

2 Position Double

Grommet (G): VQZ125 ⁰₁(R)-□G□1-01



SMC

L-type plug connector (L): VQZ125 ⁰₁ (R)-□L□1-01



M-type plug connector (M): VQZ125⁰₁ (R)-□M□1-01



Unless otherwise indicated, dimensions are the same as Grommet (G). []: AC

Dimensions: VQZ1000

3 Position Closed Center/Exhaust Center/Pressure Center (Except metal seal type)

Grommet (G): VQZ1 $\frac{3}{5}$ 5 $\frac{1}{1}$ (R)- \Box G \Box 1-01



L-type plug connector (L): VQZ1 $\frac{3}{5}$ 5 $\frac{5}{1}$ (R)- \Box L \Box 1-01







Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ2000



L-type plug connector (L): VQZ2 ¹/₈ 5⁰₁ (R)-□L□1-⁰¹₀₂



Unless otherwise indicated, dimensions are the same as Grommet (G).

M-type plug connector (M): VQZ2 $\frac{1}{8}$ 5 $^{0}_{1}$ (R)- \Box M \Box 1- $^{01}_{02}$



DIN terminal (Y): VQZ2 ¹/₉ 5⁰/₁(R)-□Y□1-⁰¹₀₂



Unless c []: AC

SMC

Dimensions: VQZ2000



L-type plug connector (L): VQZ225⁰₁ (R)-□L□1-⁰¹₀₂



M-type plug connector (M): VQZ225⁰₁ (R)-DMD1-⁰¹₀₂



Unless otherwise indicated, dimensions are the same as Grommet (G).
[]: AC

DIN terminal (Y): VQZ225 ⁰₁ (R)-□Y□1-⁰¹₀₂



Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ2000



SMC

L-type plug connector (L): VQZ2 $\frac{3}{5}$ 5 $\frac{0}{1}$ (R)- \Box L \Box 1- $\frac{01}{02}$



M-type plug connector (M): VQZ2 $\frac{3}{5}$ 5 $\frac{5}{1}$ (R)- \Box M \Box 1 $\frac{01}{02}$



DIN terminal (Y): VQZ2 $\frac{3}{5}$ 5 $\frac{1}{1}$ (R)- \Box Y \Box 1- $\frac{01}{02}$



Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ3000



Dimensions: VQZ3000



SMC

Unless otherwise indicated, dimensions are the same as Grommet (G). []: AC







Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ3000



L-type plug connector (L): VQZ3 $\frac{3}{5}$ 5 $\frac{5}{1}$ (R)- \Box L \Box 1- $\frac{02}{03}$



M-type plug connector (M): VQZ3 $\frac{3}{4}$ 5 $\frac{0}{1}$ (R)- \Box M \Box 1 $\frac{02}{03}$





DIN terminal (Y): VQZ3 $\frac{3}{5}$ 5 $\frac{1}{1}$ (R)- \Box Y \Box 1- $\frac{02}{03}$

Unless otherwise indicated, dimensions are the same as Grommet (G).

Base Mounted

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Manifold Connector Kit (C [Option]



Manifold Specifications

	all?	Series Base model		Piping P direction 1(P), 3/5(R)		fications ort size 4(A), 2(B)	Applicable solenoid valve	Applicable stations	Note) Manifold base weight (g)
-111	AL SECTO	VQZ1000	VV5QZ15-□□□	Side	Rc1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡50 VQZ1⊡51	2 to 20 stations	2 stations: 105 Addition per station: 27
		VQZ2000	VV5QZ25-□□□	Side	Rc1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2⊡50 VQZ2⊡51	2 to 20 stations	2 stations: 193 Addition per station: 54
		VQZ3000	VV5QZ35-□□□	Side	1(P) port Rc 3/8 3/5(R) port Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3⊡50 VQZ3⊡51	2 to 20 stations	2 stations: 398 Addition per station: 102
		Note	Weight without sub-pla	ate.			1		

How to Order Manifold Assembly (Example)



Dimensions: VQZ1000



/	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	73	85.5	98	110.5	110.5	123	135.5	148	160.5	173	185.5	185.5	198	210.5	223	235.5	248	248	260.5
L2	62.5	75	87.5	100	100	112.5	125	137.5	150	162.5	175	175	187.5	200	212.5	225	237.5	237.5	250
L3	38.5	49	59.5	70	80.5	91	101.5	112	122.5	133	143.5	154	164.5	175	185.5	196	206.5	217	227.5
L4	17.5	18.5	19.5	20.5	15	16	17	18	19	20	21	16	17	18	19	20	21	15.5	16.5
L5	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5

SMC



Dimensions: VQZ2000



VV5QZ35- Stations Port size C PE port D side U side 71.5 M5 x 0.8 Approx. 300 (Lead wire length) Grommet (G) L3 L4 (X: External pilot port) (For external pilot) 56.1 (Pitch) 37 (DIN rail clamp thread) 26 P = 20 20.5 (DIN rail) 3/8 19.1 [1(P) port] (8) 5.5) 58. σ 35. 130.7 35) 36.9 4 4 50 4 x ø4.5 (For mounting) Manual override (5.5)11 L5 1/4 [5(R1), 3(R2) port] L2 (5) (Rail mounting hole pitch: 12.5) L1 (Station 1) ----- (Station n) One-touch fitting [4(A), 2(B) port] 9.4 Applicable tubing O.D.: ø6, ø1/4" ø8, ø5/16" ø10, ø3/8" 28.9 4 (Pitch) (11.8) (7.5) 22.9 P = 20 1/4 [4(A), 2(B) port] 4 28.9 6111 9.4 7.4 (Pitch) 26.6 P = 20 1/4 The dashed lines indicate the DIN rail mounting [-D]. L-type plug connector (L) M-type plug connector (M) DIN terminal (Y) Applicable cable O.D. (Lead wire length) Approx. 300 ø3.5 to ø7 100.8 93.3 9 71.5 [78.5] 82 Max. [60.3] Pg7 Approx. 300 82.8 [89.8] 58.1 (Lead wire length) 67.9 [70. 75.8 76. 136.8 [141.2] 50.3 [154.7] 117.2 [121.6] \odot Œ 130.7 [135.1] 152.6 166.1 154.4 167.9 \oplus \oplus H The dashed lines indicate the DIN rail The dashed lines indicate the DIN rail H mounting [-D]. mounting [-D]. The dashed lines indicate the DIN rail mounting [-D]. Unless otherwise indicated, dimensions Unless otherwise indicated, dimensions are the same as Grommet (G). are the same as Grommet (G). Unless otherwise indicated, dimensions are the same as []: AC []: AC Grommet (G). S)

Dimensions: VQZ3000

Dimer	nsions										Form	nula: L1	= 20n +	10 L2	= 20n +	32 n:S	tations (I	Max. 20	stations)
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	110.5	123	148	173	185.5	210.5	223	248	273	285.5	310.5	323	348	373	385.5	410.5	423	448	473
L2	100	112.5	137.5	162.5	175	200	212.5	237.5	262.5	275	300	312.5	337.5	362.5	375	400	412.5	437.5	462.5
L3	72	92	112	132	152	172	192	212	232	252	272	292	312	332	352	372	392	412	432
L4	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5
L5	50	70	90	110	130	150	170	190	210	230	250	270	290	310	330	350	370	390	410
46																			



Manifold Options

Blanking plate assembly VVQZ1000-10A-5 (for VQZ1000) VVQZ2000-10A-5 (for VQZ2000) VVQZ3000-10A-5 (for VQZ3000)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



Restrictor spacer (Applicable to VQZ2000) VVQZ2000-20A-5

Mount a restrictor spacer between manifold base and valve, and thus making it possible to control cylinder speed by meter-out.



Individual SUP spacer VVQZ1000-P-5-M5 (-Q) (for VQZ1000) VVQZ2000-P-5-01 (-Q) (for VQZ2000) VVQZ3000-P-5-02 (-Q) (for VQZ3000)

Supply port can be installed individually by mounting an individual supply spacer onto the manifold block. It's used for such cases that the different pressure should be supplied into each valve, etc.



	M5:VQZ1000
/	Rc1/8:VQZ2000
	Rc1/4:VQZ3000

Dimensions

Model	Α	В	С	D Note)
VQZ1000	29	35	40	67
VQZ2000	33	43	52	81
VQZ3000	41	52	63	93
Note) Gromm	not			

Individual EXH spacer VVQZ1000-R-5-M5 (-Q) (for VQZ1000) VVQZ2000-R-5-01 (-Q) (for VQZ2000) VVQZ3000-R-5-02 (-Q) (for VQZ3000)

Exhaust port can be installed individually by mounting an individual exhaust spacer on to the manifold block. It's used for such cases that the valve exhaust is likely to affect other stations due to circuit, etc.

Port plug VVQZ1000-CP (for VQZ1000) VVQZ2000-CP (for VQZ2000) VVQZ3000-CP (for VQZ3000)

Used to block a cylinder port when changing 5 port valves into 3 port valves, etc.



Μ	15:VQZ1000
R	c1/8:VQZ2000
R	c1/4:VQZ3000

Dimensions

Model	Α	В	С	D Note)		
VQZ1000	29	35	40	67		
VQZ2000	33	43	52	81		
VQZ3000	41	52	63	93		
Note) Grommet						



Manifold Options

Name plate [-N] (Applicable to VQZ2000/3000) VVQZ2000-N5- Stations (for VQZ2000) VVQZ3000-N5- Stations (for VQZ3000)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.

- To order a manifold with nameplate already attached, insert "N" at the end of the manifold number.
- * 4 clips are attached for name plate mounting.

DIN rail AXT100-DR-

* As for □, enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail. Order it by indicating an option symbol for DIN rail mounting, -D.

The DIN rail is approximately 30 mm longer than the length of manifold.

	a //	J.	1	
۲ >		>	>	
s. R				
1	X	X		
		ĮH		
×	۹Ľ.	<u>8</u> 8i	500	
	\checkmark	-		





L Dimension L = 12.5n + 10.5										10.5										
No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

Blanking plug KQ2P-23 KQ2P-04 KQ2P-06 KQ2P-08 **KQ2P-10**





Dimensions (mm								
Applicable fitting size ød	Model	Α	L	D				
3.2	KQ2P-23	16	31.5	3.2				
4	KQ2P-04	16	32	6				
6	KQ2P-06	18	35	8				
8	KQ2P-08	20.5	39	10				
10	KQ2P-10	22	43	12				

Silencer (for manifold EXH port)

Silencer is installed in the manifold EXH port.





Model	Silencer part no.
VQZ1000	AN110-01
VQZ2000	AN200-02
VQZ3000	AN200-02

<Check valve operating principle>

Cylinder side pres

(P2

sure

SLIP side pressure (P1)

Manifold Options

Perfect block (Separated): For VQZ1000 VQ1000-FPG-

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the perfect block with a built-in pilot type perfect valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time. The combination of a 2 position single or double solenoid with a perfect block will prevent the cylinder from "dropping" at stroke end when residual supply pressure is released.

Specifications

Maximum operating pressure	0.8 MPa
Minimum operating pressure	0.15 MPa
Ambient and fluid temperature	–5 to 50°C
Flow characteristics: C	3.0 dm ³ /(s⋅bar)
Max. operating frequency	180 c.p.m



Note) Based on JIS B 8375-1981

Manifold Options

Perfect block (Separated): For VQZ2000/3000 VQ2000-FPG-

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the perfect block with a built-in pilot type perfect valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time. The combination of a 2 position single or double solenoid with a perfect block will prevent the cylinder from "dropping" at stroke end when residual supply pressure is released.

Specifications

Maximum operating pressure	0.8 MPa
Minimum operating pressure	0.15 MPa
Ambient and fluid temperature	–5 to 50°C
Flow characteristics: C	3.0 dm ³ /(s⋅bar)
Max. operating frequency	180 c.p.m



Cylinder side pressure (P2)

5

<Check valve operating principle>



Dimensions



Compact Body Type with Restrictor: For VQZ2000

• Restrictors are built into the valve body, making it easier to adjust cylinder speed.

Specifications



Dimensions: VQZ2000 (Compact Body Type: Single Unit)

VQZ2□5입□□-□G□1-01-C-□



SMC



Unless otherwise indicated, dimensions are the same as Grommet (G).



Unless otherwise indicated, dimensions are the same as Grommet (G).



Dimensions: VQZ2000 (Compact Body Type: Manifold)

20.5 15.5 16.5 17.5 15.5 18.5 16.5



L3

L4

L5

19.5



External Pilot Specification

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.2 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.



Ø SMC

Series VQZ Base Mounted **Replacement Parts**

One-touch Fitting Assembly (for Cylinder port)

Fitting size Model	СЗ	C4	C6	C8	C10
VQZ1000	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	—
VQZ2000	—	VVQ1000-51A-C4	VVQ1000-51A-C6	VVQ1000-51A-C8	—
VQZ3000	_	—	VVQ2000-51A-C6	VVQ2000-51A-C8	VVQ2000-51A-C10

Note) Purchasing order is available in units of 10 pieces.

<Plug connector assembly> DC: SY100-30-4A-100 VAC: SY100-30-1A-

200 VAC: SY100-30-2A-

Other AC voltages: SY100-30-3A-

Without lead wire: SY100-30-A (with connector and 2 sockets only)

Lead wire length

Nil	300 mm
6	600 mm
10	1000 mm
15	1500 mm
20	2000 mm
25	2500 mm
30	3000 mm
50	5000 mm

V111 5 Function Symbol Specifications DC AC 0.35 W Nil Standard \bigcirc (0.9 W) B Note) High speed response type High pressure type (0.9 W) K Note) (Metal seal type only)

<Pilot valve assembly>

(;		
	Ap att	opli tacl	cable model (Length of screws ned is different from each other.)
	N	lil	VQZ2000/3000
		4	A and B side of VQZ1000 single, double solenoid type A side of VQZ1000 3 position
		5	B side of VQZ1000 3 position

Note) Option

1	100 VAC (50/60 Hz)	
2	200 VAC (50/60 Hz)	
3	110 VAC [115 VAC] (50/60 Hz)	
4	220 VAC [230 VAC] (50/60 Hz)	
5	24 VDC	
6	12 VDC	

		Electrica	l entry 🜢
Symbol		Electrical entry	Light/surge voltage
DC	AC		suppressor
G	—	Grommet (DC specification)	None
LU	LZ	L-type plug connector with lead wire	
LOU	LOZ	Z L-type plug connector without connector	
MU MZ M-type plug connector with lead wire		162	
MOU	MOZ	OZ M-type plug connector without connector	

How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Example) In case of 2000 mm of lead wire

DC	
VQZ	1150-5LO1-
SY10	0-30-4A-20

-5LO1-M5 VQZ1150-1LO1-M5 SY100-30-1A-20

<Gasket and screw assembly>

AC



<Sub-plate>

Model	Sub-plate part no.
VQZ1000	VQZ1000-S-01 🖹 (-Q)
VQZ2000	VQZ2000-S- ⁰¹ 🖹 (-Q)
VQZ3000	VQZ3000-S- ⁰² 📧 (-Q)

* Thread type

<DIN terminal type (Applicable to the VQZ2000/3000)>

	V	115	5	_	5	Y	-	-X 1	10
	F	unct	ion 🖡						
Symbol	Specifications	DC	AC						
Nil	Standard	(0.35 W)	0						
B Note)	High speed response type	(0.9 W)	_						
K Note)	High pressure type (Metal seal type only)	(0.9 W)	_						
$\overline{\mathcal{O}}^{N}$	ote) Option								
	Coil volta	ge 🗕				_			
1	100 VAC (50/60 Hz)								С
2	200 VAC (50/60 Hz)								

100 VAC (50/60 Hz)
200 VAC (50/60 Hz)
110 VAC [115 VAC] (50/60 Hz)
220 VAC [230 VAC] (50/60 Hz)

110 VAC [115 VAC] (50/60 Hz)
220 VAC [230 VAC] (50/60 Hz)
24 VDC
12 VDC

	Electrical	entry	
Symbol	Electrical entry	Light/surge voltage suppressor	
Y	DIN terminal	Nono	
YO	DIN terminal without connector		
Ϋ́Z	DIN terminal with light/surge voltage suppressor	Yes	
YS	DIN terminal with surge voltage suppressor (DC specification)	Yes	
YOS	DIN terminal with surge voltage suppressor, without connector (DC specification)	light)	
Note) For AC voltage valves there is no "S" option. It is			

already built-in to the rectifier circuit.

/!\ Caution

When replacing only the pilot valve assembly, use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.

Series VQZ

For details of "Gateway System Serial Transmission System, Series EX510", refer to CAT.E02-22B catalog.

Gateway System Serial Transmission System EX510 Series

• All wires can be plugged into the connector units.



EX510 Gateway System Serial Transmission System Series VQZ1000/2000/3000 **Base Mounted Manifold** CE [Option]

How to Order Manifold VV5QZ 1 5-SA 08 C4 CE compliant Series Nil CE marked C 1 VQZ1000 Option 2 VQZ2000 3 VQZ3000 Nil None D With DIN rail (Rail length: Standard) SI unit • D0 Note 1) +COM. Without DIN rail (With bracket) Nil N Note 2) Name plate (Except VQZ1000) Ν -COM Special wiring specification (Except double wiring) Κ Stations R Note 2) External pilot type (Except VQZ1000) Symbol No. of stations Note 1) Order DIN rail separately. For DIN rail part no., refer to page 48. 02 2 stations Note 2) For details on options and external pilot type, refer to page 54. Note 3) When two or more symbols are specified, indicate them alpha-08 8 stations betically. Note) Maximum 16 stations Thread type (For special wiring specifi-Nil Rc cations, indicate separately by the manifold specifica-Ν NPT tion sheet.) т NPTF

How to Order Valve Manifold Assembly (Example)



is shipped with the valves (including blanking plates) and connector assembly mounted on it, as the standard specification. Be sure to specify the part nos. of the solenoid valves to be mounted.

F A, B port size

Thread piping

Symbol	Port size	VQZ1000	VQZ2000	VQZ3000
M5	M5 x 0.8	0	—	—
01	1/8		0	
02	1/4			0

One-touch fitting (Metric size)

G

Symbol	Port size	VQZ1000	VQZ2000	VQZ3000
C3	ø3.2 one-touch fitting	0	_	_
C4	ø4 one-touch fitting	0	0	-
C6	ø6 one-touch fitting	0	0	0
C8	ø8 one-touch fitting		0	0
C10	ø10 one-touch fitting	_	_	0
СМ	Mixture of port sizes	0	0	0

One-touch fitting (Inch size)

Symbol	Port size	VQZ1000	VQZ2000	VQZ3000
N1	ø1/8" one-touch fitting	0		—
N3	ø5/32" one-touch fitting	0	0	—
N7	ø1/4" one-touch fitting	0	0	0
N9	ø5/16" one-touch fitting	-	0	0
N11	ø3/8" one-touch fitting	_	_	0
NM	Mixture of port sizes	0	0	0

SI Unit Part No.

Symbol	SI unit spec.	SI unit part no.
Nil	NPN output (+COM.)	EX510-S001
Ν	PNP output (-COM.)	EX510-S101

For details of "Gateway System Serial Transmission System, Series EX510", refer to CAT.E02-22B catalog.



Note 1) Option

Note 2) For details on external pilot type, refer to page 54.

(For details, refer to page 63.)

Symbol	Description
X30	Pilot valve common exhaust
X90	Main valve fluoro-rubber
X113	All fluoro-rubber

Made to Order

Dimensions: VQZ1000-SA



The dashed lines indicate the DIN rail mounting [-D].

Unless otherwise indicated, dimensions are the same as L-type plug connector (L). []: AC

Dimensions

Dimensions Max									Max. 16	stations					
L _ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	123	123	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248
L2	112.5	112.5	112.5	112.5	112.5	125	137.5	150	162.5	175	187.5	200	212.5	225	237.5
L3	88	88	88	88	88	100	112	124	136	148	160	172	184	196	208
L4	17.5	17.5	17.5	17.5	17.5	17.5	18	18.5	18.5	19	19	19.5	19.5	20	20
L5	80	80	80	80	80	92	104	116	128	140	152	164	176	188	200

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.



Dimensions: VQZ2000-SA



Note) The L dimension of 2 to 5 stations is the same. Valves are numbered from the D side according up to the number of stations.

17.5

15.5

L4

L5



16.5

20.5

18.5

19.5

Dimensions: VQZ3000-SA



Unless otherwise indicated, dimensions are the same as L-type plug connector (L). []: AC

Dimensions

Dimensions Max										Max. 16	stations				
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	148	173	185.5	210.5	223	248	273	285.5	310.5	323	348	373	385.5
L2	112.5	112.5	137.5	162.5	175	200	212.5	237.5	262.5	275	300	312.5	337.5	362.5	375
L3	92	92	112	132	152	172	192	212	232	252	272	292	312	332	352
L4	15.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17
L5	70	70	90	110	130	150	170	190	210	230	250	170	290	310	330

Note) The L dimension of 2 to 3 stations is the same. Valves are numbered from the D side according up to the number of stations.



Manifold Options

Connector assembly

Single solenoid (SY3000-37-81A-D-N)





Connector Assembly Part No. (for a manifold with 8 stations or less with an unspecified layout) Bar Stock Type

Model	Part no.	Connector mounting position
	SY3000-37-81A-3-N	Single: for 1 to 4 stations
V/VE0712	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations
VVJQZIZ	SY3000-37-81A-2-N	Single: for 5 to 8 stations
	SY3000-37-81A-3-6	Double/3 position: for 5 to 8 stations
V/VE O7 00	SY3000-37-81A-3-N	Single: for 1 to 8 stations
VV5QZZZ	SY3000-37-81A-3-6	Double/3 position: for 1 to 8 stations
	SY3000-37-81A-3-N	Single: for 1 to 4 stations
	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations
VV5QZ32	SY3000-37-81A-4-N	Single: for 5 to 8 stations
	SY3000-37-81A-4-7	Double/3 position: for 5 to 8 stations

Note) There are no part nos. on the connectors of connector assemblies.

Connector assembly

SY3000-37-80A-



Housing (1 set: 8 pieces) SY3000-44-3A



Connector Assembly Part No. (for a manifold with a specified layout)

Model	Part no.	Connector mounting position			
	SY3000-37-80A-3	A side	For 1 to 0 stations		
V/VEO710	SY3000-37-80A-6	B side	FULL I TO 6 STATIONS		
VVSQZIZ	SY3000-37-80A-4	A side	For 0 to 16 stations		
	SY3000-37-80A-7	SY3000-37-80A-7 B side			
	SY3000-37-80A-3	A side			
V/VEO 7 00	SY3000-37-80A-6	B side	For 1 to 8 stations		
VV5QZ22	SY3000-37-80A-7	A side	For 0 to 10 stations		
	SY3000-37-80A-9	B side	For 9 to 16 stations		
	SY3000-37-80A-4	A side			
V/VEO 7 20	SY3000-37-80A-7	B side	For 1 to 8 stations		
VV5QZ32	SY3000-37-80A-8	A side			
	SY3000-37-80A-11	B side	FOT 9 10 16 STATIONS		

Note 1) Since these connector assemblies are used when adding stations or for maintenance, there are no part nos. on them.

Note 2) After inserting the connector assembly into the housing, slightly pull the lead wire to make sure it does not pull out. Do not reuse the lead wire once it has been inserted.

Note 3) Please note that the wires are longer than the actual wiring distance.





Please contact SMC for detailed dimensions, specifications, and lead times.

1 Pilot Valve Common Exhaust Specification

Pilot exhaust is exhausted through the main R port.

- * Not designed to prevent leakage to outside.
- * A combination of external pilots is not available.
- * A combination of metal seal and 2 position double is not available.
- * "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ1000/2000/3000





2 Main Valve Fluoro-rubber Specification

The seal material, the part of the main valve in contact with fluid, is made of fluoro-rubber. * "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ1000/2000/3000



3 All Fluoro-rubber Specification

The rubber material of the part in contact with fluid, is made of fluoro-rubber.

* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ1000/2000/3000

How to Order



Series VQZ Safety Instructions

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of **"Caution"**, **"Warning"** or **"Danger"**. To ensure safety, be sure to observe ISO 4414 ^{Note 1}, JIS B 8370 ^{Note 2}) and other safety practices.

Explanation of the Labels

Labels	Explanation of the labels
\land Danger	In extreme conditions, there is a possible result of serious injury or loss of life.
\land Warning	Operator error could result in serious injury or loss of life.
A Caution	Operator error could result in injury Note 3) or equipment damage. Note 4)

Note 1) ISO 4414: Pneumatic fluid power - General rules relating to systems

Note 2) JIS B 8370: General Rules for Pneumatic Equipment

Note 3) Injury indicates light wounds, burns and electrical shocks that do not require hospitalization or hospital visits for long-term medical treatment. Note 4) Equipment damage refers to extensive damage to the equipment and surrounding devices.

■ Selection/Handling/Applications

1. The compatibility of the pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or post analysis and/or tests to meet the specific requirements. The expected performance and safety assurance are the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalog information with a view to giving due consideration to any possibility of equipment failure when configuring a system.

- 2. Only trained personnel should operate pneumatically operated machinery and equipment. Compressed air can be dangerous if handled incorrectly. Assembly, handling or repair of the systems using pneumatic equipment should be performed by trained and experienced operators. (Understanding JIS B 8370 General Rules for Pneumatic Equipment, and other safety rules are included.)
- 3. Do not service machinery/equipment or attempt to remove components until safety is confirmed.
 - 1. Inspection and maintenance of machinery/equipment should only be performed once measures to prevent falling or runaway of the driven objects have been confirmed.
 - When equipment is removed, confirm the safety process as mentioned above. Turn off the supply pressure for this equipment and exhaust all residual compressed air in the system, and release all the energy (liquid pressure, spring, condenser, gravity).
 Before machinery/equipment is restarted, take measures to prevent quick extension of a cylinder piston rod, etc.
- 4. If the equipment will be used in the following conditions or environment, please contact SMC first and be sure to take all necessary safety precautions.
 - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
 - 2. Installation on equipment in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverages, recreation equipment, emergency stop circuits, clutch and brake circuits in press applications, or safety equipment.
 - An application which has the possibility of having negative effects on people, property, requiring special safety analysis.
 If the products are used in an interlock circuit, prepare a double interlock style circuit with a mechanical protection function for the prevention of a breakdown. And, examine the devices periodically if they function normally or not.

■Exemption from Liability

- 1. SMC, its officers and employees shall be exempted from liability for any loss or damage arising out of earthquakes or fire, action by a third person, accidents, customer error with or without intention, product misuse, and any other damages caused by abnormal operating conditions.
- 2. SMC, its officers and employees shall be exempted from liability for any direct or indirect loss or damage, including consequential loss or damage, loss of profits, or loss of chance, claims, demands, proceedings, costs, expenses, awards, judgments and any other liability whatsoever including legal costs and expenses, which may be suffered or incurred, whether in tort (including negligence), contract, breach of statutory duty, equity or otherwise.
- 3. SMC is exempted from liability for any damages caused by operations not contained in the catalogs and/or instruction manuals, and operations outside of the specification range.
- 4. SMC is exempted from liability for any loss or damage whatsoever caused by malfunctions of its products when combined with other devices or software.



Series VQZ Specific Product Precautions 1

Be sure to read this before handling.

For Safety Instructions and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

Manual Override

ACaution

Without an electric signal for the solenoid valve the manual override is used for switching the main valve. Push type is standard. Locking type (Tool required) is available as an option.

Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

Locking type (Tool required)



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

Locked position



Precautions

When operating with a screwdriver, turn it gently using a watchmaker's screwdriver. (Torque: less than 0.1 N•m)

How to Use L/M-Type Plug Connector

A Caution

1. Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



Light/Surge Voltage Suppressor

A Caution

1. L/M-type plug connector



<AC>



2. DIN terminal <DC>

<AC>

With light (YZ)

With light/surge voltage suppressor (YS, YOS)



Light/surge voltage suppressor (YZ)



Note) Surge voltage suppressor of varistor has residual voltage corresponding to the protective element and rated voltage; therefore, protect the controller side from the surge.

3. Surge voltage countermeasures

When shutting off the DC power supply using an emergency circuit breaker, the valve may operate incorrectly due to surge voltage generated by other electric parts (e.g., the solenoid). To ensure that surge does not affect the valve, take anti-surge measures (diode for surge protection, etc.) or use a valve with diode to prevent reverse current. (Contact SMC for model numbers.)

Circuit example



 (1), (3): Examples of anti-surge measures
 (2): Valve equipped with diode to prevent reverse current



Series VQZ Specific Product Precautions 2

Be sure to read this before handling.

For Safety Instructions and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

Lead Wire Connection

A Caution

1. Crimping of lead wires and sockets

Not necessary if ordering the lead wire pre-connected model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.



Crimping tool part no. DXT170-75-1

2. Attaching and detaching sockets with lead wires

Attaching

Insert the sockets into the square holes of the connector (\oplus, \ominus) indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.



Valve and Pilot Valve Replacement

A Caution

1. When replacing a conventional type valve with a new type for maintenance or other reasons, a "conversion connector assembly" is necessary to convert the connector from 3 terminals to 2 terminals and must be ordered separately. (When ordering, refer to the below part nos.)

For pilot valves, there is no compatibility between the conventional type and new type. When replacing a pilot valve, be sure to confirm whether it is the new type or the conventional type.

[Conventional]



[New]




Be sure to read this before handling.

For Safety Instructions and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

How to Use DIN Terminal

1. Conforming to ISO#: EN-175301-803C (Former DIN 43650C)

(8 mm between pins)

The DIN terminal type with an IP65 enclosure is protected against dust and water, however, it must not be used in water.

2. Connection

- 1) Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- 2) After removing the holding screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- 3) Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.
- 4) Secure the cord by fastening the ground nut.

3. Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at 90° intervals).

* When equipped with a light, be careful not to damage the light with the cord's lead wires.

4. Precautions

Plug in and pull out the connector vertically without tilting to one side.

5. Compatible cable

Cable O.D.: ø3.5 to ø7

(Reference) 0.5 mm², 2-core or 3-core, equivalent to JIS C 3306



DIN Connector Part No.

Without light

Rated voltage	Voltage symbol	Part no.
All voltages	None	SY100-82-1

With light

manigine		
Rated voltage	Voltage symbol	Part no.
24 VDC	24 V	SY100-82-3-05
12 VDC	12 V	SY100-82-3-06
100 VAC	100 V	SY100-82-2-01
200 VAC	200 V	SY100-82-2-02
110 VAC (115 VAC)	110 V	SY100-82-2-03
220 VAC (230 VAC)	220 V	SY100-82-2-04

Circuit diagram with light



Fitting and Silencer Part No. for P, R Ports When Using Valve as an Individual Unit

Part no. for one-touch fitting for 1(P) port and silencer/one-touch fitting for 3(R2, R), 5(R1) port

Cariaa	(1) One-touch fitting for 1(P) port	(2) For 3(R2, R) port, 5(R1) port		
Series		Silencer	One-touch fitting	
VQZ1000	KQ2H06-M5	AN120-M5	KJS04-M5	
VQZ2000	KQ2S06-01S	INA-25-46	IN-457-32L (for ø6)	
VQZ3000	KQ2H08-02S	AN101-01	KQ2H06-01S	

The diameter of the above fitting and silencer is the maximum diameter to in the EXH port.





Be sure to read this before handling.

For Safety Instructions and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

3 Port Valve for Mixture Mounting

1. Body ported (VQZ $\frac{1}{3}82^{\circ}$, N.C./VQZ $\frac{1}{3}92^{\circ}$, N.O.)

Even though 3 port valves have the same construction as the 5 port single solenoid valves, the port plug is installed in the 2(B) port for N.C. type, and 4(A) port for N.O. type. By changing the port plug into a fitting, it can be used as the 5 port single solenoid valves, too.



2. Base mounted (VQZ ¹/₃85[°]₁, N.C./VQZ ¹/₃95[°]₁, N.O.)

3 port valves have the same external appearance as the 5 port valves. When using this type, 4(A) port on the 3 port valves can be used as 4(A) port on the 5 port valves' manifold, too. Besides, there's no problem, even though 2(B) port can be either plugged or unplugged.



When port plug is used on 2 (B) port, indicate CM in manifold part no. and port size, and specify the port plug location by the manifold specification sheet. **One-touch Fittings Replacement**

ACaution

The built-in fittings on the manifold can be changed easily. Simply remove the corresponding valve and take out the fitting clip underneath.

Take out the clip with a screwdriver, etc., then replace the fittings. About mounting the fittings, after inserting the fitting until it stops, then put the clip into the prescribed position.



VQZ1000/2000: Horizontally clipped to the valve body VQZ3000: Vertically clipped to the valve body



Precautions

When pulling the fitting assembly away from the valve base, remove the clip, then connect a tube or plug (KQP- \Box) with the one-touch fitting and pull it out holding the tube or plug. Do not hold the release bushing to avoid damage.



Be sure to read this before handling.

For 5 Port Solenoid Valve and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

DIN Rail Removal/Mounting

▲Caution

1. Removing

- 1) Loosen the clamp screw on the (a) side of both ends of the manifold.
- Lift the ⓐ side → of the manifold off the DIN rail and slide it in the direction of the ⓑ side.

2. Mounting

- 1) Catch the hook of the DIN rail bracket on the side on the DIN rail.
- 2) Push side (a) onto the DIN rail and tighten the clamp screw. The proper tightening torque for screws is 0.3 to 0.4 N•m.



Valve Mounting

A Caution

1. After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.

Model	Proper tightening torque
VQZ1000	0.18 to 0.25 N•m
VQZ2000	0.25 to 0.35 N•m
VQZ3000	0.5 to 0.7 N•m



Serial Wiring EX510 Precautions

Design and Selection

A Warning

1. Use within the allowable voltage range.

Using beyond the allowable voltage range is likely to cause the units and connecting devices to be damaged or to malfunction.

- **2. Do not use beyond the specified range.** Using beyond the specified range is likely to cause a fire, malfunction, or breakdown in the units and connecting devices. Check the specifications before handling.
- 3. Establish a backup system beforehand, which employs fail-safe concepts such as multiple equipment and devices to prevent breakage or malfunction of this product.
- 4. Provide an external emergency stop circuit that will immediately stop an operation and cut off the power supply.

5. When using for an interlock circuit:

- Provide a double interlock which is operated by another system (such mechanical protection function).
- Perform an inspection to check that it is working properly because it can cause possible injuries.





Be sure to read this before handling. For 5 Port Solenoid Valve and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

Serial Wiring EX510 Precautions

Design and Selection

A Caution

1. Keep the surrounding space free for maintenace.

When designing a system, take into consideration the amount of free space needed for performing maintenance.

- 2. Use the following UL approved products for DC power supply combinations.
 - 1) Controlled voltage current circuit conforming to UL508 Circuit uses the secondary coil of an isolated transformer as the power supply, satisfying the following conditions.
 - Max. voltage (with no load): 30 Vrms (42.4 V peak) or less
 Max. current: (1) 8 A or less (including shorts), and
 - (2) When controlled by a circuit protector (fuse, etc.) with the following rating

No-load voltage (V peak)	Max. current rating	
0 to 20 [V]	5.0	
Over 20 [V] to 30 [V]	100	
	Peak voltage value	

- 2) A circuit (class 2 circuit) with maximum 30 Vrms (42.4 V peak) or less, and a power supply consisting of a class 2 power supply unit confirming to UL1310, or a class 2 transformer confirming to UL1585
- 3. This product is one of the components to be equipped into a final equipment. Confirm the adaptability to the EMC directive as the whole equipment by customers themselves.
- 4. The power supply for the Gateway unit should be 0 V as the standard for both power supply for outputs as well as inputs and for the control unit of the Gateway.



Mounting

ACaution

1. Do not drop, bump, or apply excessive impact.

Otherwise, the unit can become damaged, malfunction, or fail to function.

- **2. Hold the body while handling this product.** Otherwise, the unit can become damaged, malfunction, or fail to function.
- 3. Observe the tightening torque range. Tightening outside of the allowable torque range will likely damage the product.
- 4. Do not install a unit in a place where it can be used as a scaffold.

Applying any excessive load such as stepping on the unit by mistake or placing a foot on it, will cause it to break.

Wiring

M Warning

1. Avoid miswiring.

If miswired, there is a probability of damaging units or connecting devices.

- **2.** Do not wire while energizing the product. It is likely to damage the units or connecting devices.
- 3. Avoid wiring the power line and high pressure line in parallel.

Noise or surge produced by signal line resulting from the power line or high pressure line could cause a malfunction. Wiring of the reduced-wiring system and the power line or high pressure line should be separated from each other.

4. Confirm the wiring insulation.

Inferior insulation (contact with other circuit, insulation between terminals, etc.) will likely cause damage to the units or connecting devices due to excessive voltage or the influx of current.

A Caution

1. Take measures to avoid applying repeated bending force or pulling force to the cable.

Also, pay attention not to place any heavy matter on the cable or clipping. It is likely to cause a broken wire.

2. Confirm grounding to maintain the safety of the reduced-wiring system and for anti-noise performance.

Grounding should be close to units and keep the grounding distance short.



Be sure to read this before handling. For 5 Port Solenoid Valve and Common Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

Serial Wiring EX510 Precautions

Operating Environment

A Warning

- 1. Do not use this product in the presence of dust, particles, water, chemicals, and oil. Use with such materials is likely to cause a malfunction or breakage.
- 2. Do not use this product in the presence of a magnetic field.

Use in such an environment is likely to cause a malfunction.

3. Do not use this product in an atmosphere containing an inflammable gas, explosive gas, or corrosive gas.

Use in such an atmosphere is likely to cause a fire, explosion, or corrosion.

This reduced-wiring system is not explosion-proof.

4. Do not use this product in places where there are cyclic temperature changes.

In case that the cyclic temperature is beyond normal temperature changes, the internal unit is likely to be adversely effected.

5. Do not use this product in places where there is radiated heat around it.

Such a place is likely to cause a malfunction or breakage.

6. Do not use this product near sources that generate a surge which exceeds the benchmark test, even though this product is CEmarked certified.

The internal circuit components are likely to deteriorate or become damaged when there are equipment (solenoid type lifter, high frequency guided furnace, motor, etc.) which generate a large surge around the reduced wiring system. Take measures to prevent an electrical surge and avoid having the wires touch each other.

7. Use the product type that has an integrated surge absorption element when directly driving a load which generates surge voltage by relay or solenoid valves.

8. The reduced wiring system should be installed in places with no vibration or shock. If installed in a place with vibration or shock, a malfunction or breakage is likely to occur.

Adjustment and Operation

M Warning

1. Do not short-circuit a load.

If a load is short-circuited, excessive can cause damage to the connected devices. The fuse of the input unit will melt and below. The output and SI unit will activate its overcurrent protection function. However, they cannot cover all modes, so damage is likely to occur.

2. Do not manipulate or perform settings with wet hands.

Performing such activity will likely cause an electrical shock.

🗥 Caution

1. DIP switches and rotary switches should be set with a small watchmaker's screwdriver.

Maintenance

\land Warning

1. Do not disassemble, modify (including circuit board replacement) or repair this product.

Such actions are likely to cause injuries or breakage.

- 2. Perform periodic inspection. Confirm that wiring or screws are not loose. Otherwise, unpredicted malfunction in the system composition devices is likely to occur.
- 3. When an inspection is performed.
 - Turn off the power supply.

· Stop the supplied fluid and discharge the fluid in the piping and confirm the release to the atmosphere before performing an inspection. It is likely to cause injuiries.

A Caution

1. Do not wipe this product with chemicals such as benzine or thinner.

Using such chemicals is likely to cause damage.



Record of changes

LX

B edition * Page 2, 31 Correction of Response Time * Correction of Dimensions * Page 63 Addition of Made to Order

Safety Instructions Be sure to read "Precautions for Handling Pneumatic Devices" (M-03-E3A) before using.

SMC Corporation

Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 Fax: 03-5298-5362 URL http://www.smcworld.com © 2007 SMC Corporation All Rights Reserved

Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

D-DN 1st printing KY printing LX 13500DN Printed in Japan. This catalog is printed on recycled paper with concern for the global environment.