
Steam Valve Series VND

2 Port Valve for Steam

2 Port Valve for Steam Max. 180°C




Wide variations

2 types - N.C., N.O. Threaded type (6A to 50A) Flange type (32F to 50F)



Steam Valve: 2 Port Valve For Steam Series VND

How to Order



VINA
VNB
SGC
SGH
VNC
VNH
VND
VCC
TQ

Series VND



Model

Model	Port	size	Orifice dia.	Flow characteristics	Weight (kg)	
Model	Rc	Flange Note)	ø (mm)	Av x 10 ⁻⁶ m ²		
VND10 D-6A	1/8	-		26		
VND10D-8A	1/4	-	7	28	0.3	
VND10D-10A	3/8	-]	31		
VND20 D-10A	7 98	-	15	120	0.6	
VND20D-15A	1/2	-	1 15	130	0.6	
VND30D-20A	3/4	-	20	240	0.9	
VND40 D-25A	1	-	25	380	1.4	
VND50D-32A	11/4	-	32	440	2.3	
VND50D-32F	-	32	32	440	5.5	
VND60D-40A	11/2	-	40	920	3.6	
VND60D-40F	-	40	40	920	7.2	
VND70 D-50A	2	-	50	1500	5.7	
VND70D-50F	-	50	1 50	1500	10.8	


Note) The companion flange is JIS B 2210 10K (standard) or its equivalent.

Valve Specifications


			-					
Fluid (Main	piping)		Steam					
Fluid tempe	rature		-5 to 180°C Note 1)					
Ambient ter	nperature		-5 to 60°C Note 1)					
Proof press	ure		1.5 MPa					
Operating p	ressure range)	0 to 0.97 MPa					
		N.C.	0.3 to 0.7 MPa					
	Pressure	N.O.	0.1 + 0.25 x (Operating pressure) to 0.25 + 0.25 x					
External pilot air			(Operating pressure) MPa Refer to below "Graph (1)".					
Lubrication		n	Not required					
Temperature		ure	-5 to 60°C Note 1)					
Mounting orientation Unrest		Unrestricted						

Note 1) No freezing Note 2) Non-lubricant specifications are not available for this product.


Symbol



Graph (1) VNDD 02 D Pilot Pressure (N.O. type)



Construction



N.O.

Component Parts

No.	Description	Material	Note
1	Body	Bronze*	Clear coated
2	Cover assembly	Aluminum alloy	Platinum silver painted
3	Plate assembly	Brass*	PTFE, EPR, FKM
3 4 5	Valve element	Brass*, PTFE	-
5	Piston assembly	Aluminum alloy	—
6	Return spring	Piano wire	—
7	Second plate assembly	Aluminum alloy	—

* Body option S is made of stainless steel.

Working Principle

VND□0⁶₄□ (N.C.)

When fluid is exhausted from the port 12(P1), the value 4 connected with the piston 5 is closed by the return spring 6.

• When valve opens

When pressurized air enters through the port 12(P1), the valve piston moves upward by the pilot air that enters below the piston and the valve element opens.

When valve closes

When fluid is exhausted from the port 12(P1), the pilot air below the piston is exhausted and the valve element is closed by the return spring.


VND 02 (N.O.)

In contrast with the N.C., when air is exhausted from the port 10(P2), the return spring opens the valve element. Pressurized air that enters through the port 10(P2) closes the valve element.


VNA
VNB
SGC
SGH
VNC
VNH
VND
VCC
TQ

Series VND

Port size: 6A, 8A, 10A




Port size: 10A, 15A, 20A, 25A



Model	Main port 1(A), 2(B)	A	в	с	D	E	F	G	м	N	Р	Q	R	s	т	U
VND20D-10A	3/8	63	42	28	14	73.5	81.5	4	52	26	4.5	24.3	2.3	25	34	56
VND20 D-15A VND30 D-20A	1/2 3/4	80	50	35	17.5	85	93	5	62	31	5.5	28.3	2.3	30	43	61.5
VND40D-25A	1	90	60	40	20	101	109	6	72	36	6.5	33.3	2.3	35	49	74

Port size: 32A, 40A, 50A




Model	Main port 1(A), 2(B)	Pilot port 12(P1), 10(P2)	Α	в	с	D	E	F	G	н	J
VND50 D-32A	11/4	1/8	105	77	53	26.5	121.5	20	130.5	8	55
VND60 D-40A	11/2	1/4	120	96	60	30	138	24	148	10	63
VND70 D-50A	2	1/4	140	113	74	37	161	24	171	12	74

Port size/Flange: 32F, 40F, 50F

Model

VND70D-50F



VNB SGC SGH VNC VNH VND VCC TQ

VNA

155

163.5

24

120

54

14

1/4

50

180

251

12



Series VND **Specific Product Precautions**

Be sure to read this before handling. Refer to front matter 41 for Safety Instructions, and pages 17 to 19 for 2 Port Solenoid Valves for Fluid Control Precautions.

External Pilot

▲ Caution

Pilot port 12(P1) and 10(P2) piping P1 and P2 piping should be as follows according to the model

corung t	cording to the model.										
Port	VND O D	VND O2D									
12(P1)	External pilot	Bleed port									
10(P2)	Bleed port	External pilot									

Installing a silencer to the exhaust port and the bleed port is recommended for noise reduction and for dust entry prevention.

Piping

Caution ⚠

To use the piping with a high temperature fluid, use heat resistant fittings and tubing (Self-align fittings, PTFE tubing or Copper piping, etc.).

Adiabatic Space

▲ Caution

There is a space between body and cover (*: approximate 1 mm) for adiabatic effect.

