

Model Number

NJ2-12GM-N-V1

Features

- 2 mm flush
- Usable up to SIL 2 acc. to IEC 61508


Accessories

V1-G Female connector, M12, 4-pin, field attachable V1-W Female connector, M12, 4-pin, field attachable V1-G-N-2M-PUR Female cordset, M12, 2-pin, NAMUR, PUR cable V1-W-N-2M-PUR Female cordset, M12, 2-pin, NAMUR, PUR cable EXG-12 Quick mounting bracket with dead stop **BF 12** Mounting flange, 12 mm

Technical Data						
Gen	eral specifications					
Sv	vitching element function		NAMUR, NC			
Ra	ted operating distance	s _n	2 mm			
Ins	stallation		flush			
Οι	Itput polarity		NAMUR			
	sured operating distance	sa	0 1.62 mm			
	eduction factor r _{Al}		0.4			
	eduction factor r _{Cu}		0.3			
	duction factor r ₃₀₄		0.85			
Non	ninal ratings					
	ominal voltage	Uo	8.2 V (R _i appr			
	perating voltage	UB	5 25 V			
	vitching frequency	f	0 2000 Hz			
	rsteresis	н	3 %			
	itable for 2:1 technology		yes, Reverse			
	irrent consumption					
1	Measuring plate not detected		≥3 mA			
I	Veasuring plate detected		≤1 mA			
Functional safety related parameters						
M	rtf _d		5887 a			
	ssion Time (T _M)		20 a			
	agnostic Coverage (DC)		0 %			
Amb	pient conditions					
An	nbient temperature		-25 100 °C			
Mec	hanical specifications					
Co	onnection type		Connector M1			
	ousing material		Stainless stee			
	nsing face		PBT			
	gree of protection		IP67			
Gen	eral information					
Sc	ope of delivery		2 self locking r			
Us	e in the hazardous area		see instruction			
(Category		1G; 2G			
Compliance with standards and directives						
Standard conformity						
I	NAMUR		EN 60947-5-6			

Switching element function		NAMUR, NC
Rated operating distance	s _n	2 mm
Installation		flush
Output polarity		NAMUR
Assured operating distance	sa	0 1.62 mm
Reduction factor r _{AI}		0.4
Reduction factor r _{Cu}		0.3
Reduction factor r ₃₀₄		0.85
Nominal ratings		
Nominal voltage	Uo	8.2 V (R _i approx. 1 kΩ)
Operating voltage	UB	5 25 V
Switching frequency	f	0 2000 Hz
Hysteresis	Н	3 %
Suitable for 2:1 technology		yes, Reverse polarity protection diode not required
Current consumption		
Measuring plate not detected		≥3 mA
Measuring plate detected		≤1 mA
Functional safety related paramete	rs	
MTTF _d		5887 a
Mission Time (T _M)		20 a
Diagnostic Coverage (DC)		0 %
Ambient conditions		
Ambient temperature		-25 100 °C (-13 212 °F)
Mechanical specifications		
Connection type		Connector M12 x 1, 4-pin
Housing material		Stainless steel 1.4305 / AISI 303
Sensing face		PBT
Degree of protection		IP67
General information		
Scope of delivery		2 self locking nuts in scope of delivery
Use in the hazardous area		see instruction manuals
Category		1G; 2G
Compliance with standards and di	rective	S
Standard conformity		
NAMUR		EN 60947-5-6:2000
		IEC 60947-5-6:1999
Standards		EN 60947-5-2:2007
		IEC 60947-5-2:2007
Approvals and certificates		
FM approval		
Control drawing		116-0165
UL approval		cULus Listed, General Purpose
CSA approval		cCSAus Listed, General Purpose
CCC approval		CCC approval / marking not required for products rated ≤36 V
		\sim

CCC approval **Dimensions**



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com


Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



NJ2-12GM-N-V1

F PEPPERL+FUCHS

Electrical Connection



Pinout



Wire colors in accordance with EN 60947-5-6

1 | BN (brown) 2 | BU (blue)

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Equipment protection level Ga					
Instruction	Manual electrical apparatus for hazardous areas				
Device category 1G					
	for use in hazardous areas with gas, vapour and mist				
EC-Type Examination Certificate	PTB 00 ATEX 2048 X				
CE marking	C € 0102				
ATEX marking	↔ II 1G Ex ia IIC T6T1 Ga The Ex-related marking can also be printed on the enclosed label.				
Directive conformity	94/9/EG				
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions				
Appropriate type	NJ 2-12GM-N				
Effective internal inductivity C _i	\leq 30 nF ; a cable length of 10 m is considered.				
Effective internal inductance L _i	\leq 50 μH ; a cable length of 10 m is considered.				
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.				
Ambient temperature	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127- 1 has already been applied to the temperature table for category 1.				
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. If the Ex- related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.				
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.				
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.				
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.				
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.				

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Equipment protection level Gb				
Instruction		Manual electrical apparatus for hazardous areas		
Device category 2G		for use in hazardous areas with gas, vapour and mist		
EC-Type Examination Certificate		PTB 00 ATEX 2048 X		
CE marking		€ € 0102		
ATEX marking		(b) II 1G Ex ia IIC T6T1 Ga The Ex-related marking can also be printed on the enclosed label.		
Directive conformity		94/9/EG		
Standards		EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions		
Appropriate type		NJ 2-12GM-N		
Effective internal inductivity	C _i	\leq 30 nF ; a cable length of 10 m is considered.		
Effective internal inductance	L _i	\leq 50 μH ; a cable length of 10 m is considered.		
General		The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.		
Maximum permissible ambient ter	nperature T _{amb}	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate.		
Installation, commissioning		Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.		
Maintenance		No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.		
Special conditions		The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.		
Protection from mechanical dan	ger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.		
Electrostatic charge		Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.		

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Equipment protection level Da			
Instruction	Manual electrical apparatus for hazardous areas		
Device category 1D	for use in hazardous areas with combustible dust		
EC-Type Examination Certificate	PTB 00 ATEX 2048 X		
CE marking	C € '0102		
ATEX marking	$\langle\!$		
Directive conformity	94/9/EG		
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions		
Appropriate type	NJ 2-12GM-N		
Effective internal inductivity C _i	\leq 30 nF ; a cable length of 10 m is considered.		
Effective internal inductance L _i	\leq 50 μ H ; a cable length of 10 m is considered.		
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.		
Maximum permissible ambient temperature $\mathrm{T}_{\mathrm{amb}}$	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the surface temperature, and the effective internal reactance values can be found on the EC-type-examination certificate. The maximum permissible ambient temperature of the data sheet must be noted, in addition, the lower of the two values must be maintained.		
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indeli- ble, including in the event of possible chemical corrosion.		
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.		
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.		
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.		
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.		

Do not attach the nameplate provided in areas where electrostatic charge can build up.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 n fa-info@sg.pepperl-fuchs.com



