







# **Model Number**

NBB5-18GM60-A2-V1-3G-3D

# **Features**

- 5 mm flush
- ATEX-approval for zone 2 and zone 22

# **Accessories**

BF 18

Mounting flange, 18 mm

**EXG-18** 

Quick mounting bracket with dead stop

Technical Data		
General specifications		
Switching element function		PNP NO/NC
Rated operating distance	s <sub>n</sub>	5 mm
Installation		flush
Output polarity		DC
Assured operating distance	sa	0 4.05 mm
Reduction factor r <sub>Al</sub>		0.25
Reduction factor r <sub>Cu</sub>		0.15
Reduction factor r <sub>304</sub>		0.66
Nominal ratings		
Operating voltage	U <sub>B</sub>	10 30 V DC
Switching frequency	f	0 800 Hz
Reverse polarity protection		reverse polarity protected
Short-circuit protection		pulsing
Voltage drop	$U_d$	≤ 3 V
Operating current	ال	0 200 mA
Off-state current	l <sub>r</sub>	0 0.5 mA typ. 0.1 μA at 25 °C
No-load supply current	I <sub>o</sub>	≤ 20 mA
Switching state indicator		LED, yellow
Ambient conditions		
Ambient temperature		-25 70 °C (-13 158 °F)
Mechanical specifications		
Connection type		Connector M12 x 1, 4-pin
Housing material		brass, nickel-plated
Sensing face		PBT
Degree of protection		IP67

# Category Compliance with standards and directives

Standard conformity

General information

Standards EN 60947-5-2:2007 IEC 60947-5-2:2007


Approvals and certificates

Use in the hazardous area


UL approval	cULus Listed, General Purpose
CSA approval	cCSAus Listed, General Purpose
CCC approval	CCC approval / marking not required for products rated ≤36 V

see instruction manuals 3G; 3D

# **Dimensions**



# **Electrical Connection**



# **Pinout**



Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)

FPEPPERL+FUCHS

2

#### ATEX 3G (nA)

Instruction

# Device category 3G (nA)

Certificate of Compliance CE marking

ATEX marking

Directive conformity

Standards

General

Installation, commissioning

#### Maintenance

#### Special conditions

Maximum operating current I<sub>L</sub>

Maximum operating voltage U<sub>Bmax</sub>

Maximum permissible ambient temperature T<sub>LImax</sub>

at  $U_{Bmax}$ =30 V,  $I_{L}$ =200 mA

at  $U_{Bmax}$ =30 V,  $I_{L}$ =100 mA

at  $U_{Bmax}$ =30 V,  $I_{L}$ =50 mA

at  $U_{Bmax}$ =30 V,  $I_{L}$ =25 mA Protection from mechanical danger

Protection from UV light

Protection against transients

Electrostatic charge

Material selection accessories

Plug connector

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PF 15CERT3754 X

(€

94/9/FG

EN 60079-0:2012+A11:2013, EN 60079-15:2010

Ignition protection category "n

Use is restricted to the following stated conditions

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed

Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.

The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not permissible.

dependant of the load current I<sub>L</sub> and the max. operating voltage U<sub>Bmax</sub>. Information can be taken from the following list.

45 °C (113 °F)

49 °C (120.2 °F)

50 °C (122 °F)

51 °C (123.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

Ensure transient protection is provided and that the maximum value of the transient protection (140% of 85 V) is not exceeded.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

When selecting accessories, ensure that the material allows the temperature of the enclosure to rise to up to 70 °C.

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e. the area that is inaccessible when the connector is inserted)

#### ATEX 3D (tD)

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with combustible dust

< € | CE marking

ATEX marking ⟨Ex⟩ II 3D Ex tD A22 IP67 T80°C X

The Ex-significant identification is on the enclosed adhesive label

94/9/EG Directive conformity

EN 61241-0:2006, EN 61241-1:2004 Standards

Protection via housing "tD"
Use is restricted to the following stated conditions

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment.

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, commissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possi-

bility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Maintenance

Repairs to these apparatus are not possible.

Special conditions

Electrostatic charge

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Information can be taken from the following list.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are

dependant of the load current  $I_L$  and the max. operating voltage  $U_{\mbox{\footnotesize{Bmax}}.}$ 

not permitted.

Maximum permissible ambient tempera-

ture T<sub>Umax</sub>

at  $U_{Bmax}$ =30 V,  $I_{L}$ =200 mA 45 °C (113 °F) at  $U_{Bmax}$ =30 V,  $I_{L}$ =100 mA 49 °C (120.2 °F) at  $U_{Bmax}$ =30 V,  $I_{L}$ =50 mA 50 °C (122 °F) at  $U_{Bmax}$ =30 V,  $I_{L}$ =25 mA 51 °C (123.8 °F)

Protection from mechanical danger

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is Protection from UV light

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT Plug connector SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e.

the area that is inaccessible when the connector is inserted)

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs)

PEPPERL+FUCHS

#### ATEX 3D (tc)

Instruction

# Device category 3D

Certificate of Compliance CE marking

ATEX marking

Directive conformity

Standards

General

Installation, commissioning

Maintenance

#### Special conditions

Maximum operating current IL

Maximum operating voltage U<sub>Bmax</sub>

Maximum permissible ambient temperature T<sub>Umax</sub>

at  $U_{Bmax}$ =30 V,  $I_{L}$ =200 mA at U<sub>Bmax</sub>=30 V, I<sub>L</sub>=100 mA at  $U_{Bmax}$ =30 V,  $I_{L}$ =50 mA at  $U_{Bmax}$ =30 V,  $I_{L}$ =25 mA

Protection from mechanical danger

Protection from UV light

Electrostatic charge

Plug connector

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust PF 15CERT3774 X

(€

II 3D Ex tc IIIC T80°C Dc

the possibility of chemical corrosion!

The Ex-related marking can also be printed on the enclosed label.

94/9/FG

EN 60079-0:2012+A11:2013, EN 60079-31:2014

Protection by enclosure "tc" Some of the information in this instruction manual is more specific than the information provided in the datasheet

The corresponding datasheets, declarations of conformity, EC-type examination certificates, certifications, and control drawings, where applicable (see datasheets), form an integral part of this document. These documents can be found at www.pepperlfuchs.com. The maximum surface temperature of the device was determined without a layer of dust on the apparatus. Some of the information in this instruction manual is more

specific than the information provided in the datasheet. Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The maximum permissible load current must be restricted to the values given in the fol-

High load currents and load short-circuits are not permitted.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.

dependant of the load current  $I_L$  and the max. operating voltage  $U_{\mbox{\footnotesize{Bmax}}.}$ Information can be taken from the following list.

45 °C (113 °F) 49 °C (120.2 °F)

50 °C (122 °F)

51 °C (123.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Do not attach the nameplate provided in areas where electrostatic charge can build up.

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e. the area that is inaccessible when the connector is inserted)