

Range datasheet

# RS Pro Parabolic Rubber Damper Mounts



## Product Details –

Parabolic buffers are designed for progressive absorption of energy. They are highly deformable, which allows them to absorb large impact loads.


### Features:

- Parabolic rubber profile
- Easy to install
- Low cost
- Available in natural rubber as standard, other compounds available on request

### Applications:

- Small buffers are used to isolate panel doors on enclosed generators, car bonnets, compressors and pumps
- Large buffers are used for suspension of heavy containers on vehicles

## Line Drawing -





RS Stock number	Description	Dimensions (mm)				Max Load (KG)
		D	H	G	L	
1265957	Dampers Parabolic Bump Stop M5 x 12mm 60 ShA	10	10	M	12	10
1265958	Dampers Parabolic Buffer (M) 20x24mm M6x18 60 ShA NR	20	24	M6	18	35
1265959	Dampers Parabolic Buffer (M) 25x20mm M8x20 55 ShA NR	25	20	M8	20	48
1265960	Dampers Parabolic Buffer (M) 30x30mm M6x18 60 ShA NR	30	30	M6	17	56
1265961	Dampers Parabolic Buffer (M) 30x30mm M8x20 60 ShA NR	30	30	M8	20	56
1265962	Dampers Parabolic Buffer (M) 50x48mm M8x25 50 ShA NR	50	48	M8	25	64
1265963	Dampers Parabolic Buffer (M) 50x50mm M10x25 60 ShA NR	50	50	M10	25	184
1265964	Dampers Parabolic Buffer (M) 50x61mm M10x28 60 ShA NR	50	61	M10	28	158
1265965	Dampers Parabolic Bump Stop M8x35mm 50 shore	50	64	M8	35	70
1265966	Dampers Parabolic Buffer (M) 70x58mm M12x35 60 ShA NR	70	58	M12	37	370
1265967	Dampers Parabolic Buffer (M) 70x60mm M10x25 60 ShA NR	70	60	M12	35	366